


Installation & Instruction Manual



MGT

Note: Read this manual carefully before installing the operator and place this installation manual in an accessible place near the operator. For future reference record:

Model # _____

Date _____

Wiring Diagram # _____

Model # _____

Project No _____

Project Name _____

Door No. # _____



IMPORTANT SAFETY INSTRUCTIONS**WARNING****TO REDUCE THE RISK OF SEVERE INJURY OR DEATH, READ AND FOLLOW ALL INSTRUCTIONS**

1. Never allow children to operate or play with or near door.
2. Check to see that the operator is correct for the type, size of door and frequency of use per the operator specifications.
3. If the door system is near a residential area, or pedestrian traffic is expected near the door system, additional equipment such as electric reversing edges, photocells, or similar devices must be installed as part of the system to prevent entrapment.
4. Reversing devices appropriate to the application must be installed as part of the system.
5. Outdoor or easily accessible controls must be of the security type to prevent unauthorized use of the system.
6. Place controls far enough from the door so that a user cannot touch the door when operating the controls.
7. Controls should be placed so the user has full view of the door when operating.
8. Always keep moving door in sight and away from people or vehicles until it is completely opened or closed. **NO ONE SHOULD CROSS THE PATH OF THE MOVING DOOR.**
9. If a person is trapped under the door, push the "OPEN" control button.
10. Do not overtighten a clutch to compensate for a damaged door.
11. Test door and service monthly. After adjusting the limit travel, retest the door opener. Failure to adjust the door may cause death or injury.
12. **KEEP DOORS PROPERLY BALANCED.** See door owner's manual. An improperly balanced door could cause severe injury. Have a qualified service person make repairs to cables, spring assemblies and other hardware.
13. If possible, use the emergency release only when the door is closed. Use caution when using this release with the door open. Weak or broken springs may cause the door to fall rapidly, causing injury or death.
14. You are responsible for assuring that the owner of the door system understands its basic operation and safety. In particular, be sure the owner/end-user understands the location and operation of the manual disconnect.
15. Point out to the owner/end-user of the door system that children or pets should not be allowed to play on or near the door or any part of the system, and that the safety instructions supplied with this operator are the responsibility of the owner/end-user.
16. Leave the installation and maintenance manual for this operator as well as any additional information supplied with this operator or other components of the door system with the owner/end-user.
17. If you have any question about the safety of the door operating system, do not install the operator, contact us.

**WARNING****DO NOT CONNECT POWER SUPPLY WHILE INSTALLING, SERVICING OR ADJUSTING THE ELECTRIC OPERATOR****WARNING****NOT APPLICABLE FOR RESIDENTIAL USE. ONLY FOR INDUSTRIAL AND COMMERCIAL APPLICATIONS**

TABLE OF CONTENTS

	Page
GENERAL PARTS & SPECIFICATIONS	4
WEIGHT AND DIMENSIONS	4
PRODUCT APPLICATION	5
DELIVERY OF OPERATOR	5
HARDWARE	5
INSTALLATION	6
CLUCTH ADJUSTMENT	11
BRAKE ADJUSTMENT	11
SCHEDULED MAINTENANCE	13
MGT EXPLODED VIEW	14
SPECIFIC TO ELECTRONIC CONTROL BOARD	15
• Power, Control and Accessory Wiring	16
• Program Setting	20
• Mode Setting	21
• Door Lock Sensor	22
• Troubleshooting on ECB	23-24
• Single phase Wiring Diagram	25
• 3-phase Wiring Diagram	26
SINGLE BUTTON RADIO CONTROL & RED & GREEN WARNING LIGHTS	27
• Warning lights sequence	28
• Programming of warning lights sequence	28
• Connection of Red & Green lights	28
SPECIFIC TO HARDWIRED ELECTRIC CONTROL	29
• Wiring of a MGT	30-31
• Accessory wirind diagrams	32-33
• Troubleshooting on hardwiring circuit	36-37
• Single phase Wiring Diagram	38
• 3-phase Wiring Diagram	39
WARRANTY POLICY	40
NOTES	41-43


SPECIFICATIONS

GENERAL

SUPPLY VOLTAGE.....	115, 230 VAC single phase 208, 460, 575 VAC three phase
CONTROL VOLTAGE.....	24VAC class 2 transformer, 2 amp fuse type ACG
MOTOR.....	Continuous duty 1/2, 3/4, 1 & 1.5 Horsepower
OPERATOR OUTPUT SPEED.....	103.5 RPM
WEIGHT (net).....	126 lbs (approx), 56.8 kg
STANDARD WIRING TYPE.....	C2 momentary contact to open and stop and constant pressure to close.

DIMENSIONS

(MGT)



MGT: THE TROLLEY OPERATOR

IMPORTANT: UPON COMPLETION OF OPERATOR INSTALLATION, THIS MANUAL MUST BE GIVEN TO THE END-USER

1. PRODUCT APPLICATION

The model MGT heavy-duty trolley operator is designed for use on standard lift overhead sectional garage doors. All MGT door operators are designed and constructed in accordance with UL and CSA standards.


2. DELIVERY OF OPERATOR

Upon delivery of your heavy-duty trolley operator, inspect the unit immediately for transport damage. Verify that you have received all the hardware requested with your order (Table 1). Other items may be present, such as radio controls or other types of optional equipment, if ordered. If any item is missing or if there is evidence of damage, call the transport company first.

* Check to make sure that the available power supply to be connected to the operator is of the same voltage, frequency, phase and amperage as indicated on the nameplate of the operator

3. HARDWARE**TABLE 1 STANDARD PARTS LIST FOR MGT TROLLEY OPERATOR**

#	Qty	Code	Description	
1	1	STATION020	3 push-button station	
2	1	DOORARM001	Door lifting arm assembly	
3	2	TRACKxxx	Pre-drilled galvanized track	Txxx
4	1	CHAINxxx	#41 Drive Chain	
5	1	BRACKET043	Front end U-bracket	
6	1	FRONTIDLER007/010	#41 Front idler assembly	
7	2	SHAFT017	Spacer	
8	1	CARRIAGE006	Carriage	
9	6	BOLT026	Hex head bolt 3/8-16UNC x 1-1/4	T2-HBAG
10	1	BOLT031	Hex head bolt 3/8-16UNC x 2-1/4	
11	1	BOLT035	Take-up bolt 3/8 x 2-1/2	
12	1	LINK004	Connecting chain link	
13	8	NUT010	Hex nut 3/8-16UNC	
14	7	WASHER030	Lock washer 3/8	
15	1	NUT022	Stop nut 3/8	

*Figure 1 Hardware*

4. INSTALLATION

All heavy-duty trolley operators are tested and adjusted at the factory. When installing your unit, please note that the cams are resting in the center of the camshaft.

4.1 IMPORTANT INSTALLATION INSTRUCTIONS



WARNING

TO REDUCE THE RISK OF SEVERE INJURY OR DEATH, READ AND FOLLOW ALL INSTALLATION INSTRUCTIONS

1. Installation of this door operator must be done by a qualified installer.
2. Insure that the door is properly installed and works freely in both directions. Do not install the operator until all door problems have been corrected. If necessary, oil all moving parts (chains, rollers, guides, etc.).
3. Remove all old accessories (locks, bolts, etc.) before installing door operator.
4. Do not connect the operator to a source of power until instructed to do so.
5. Locate control push-button station within sight of the door, at a minimum height of 5 ft. (1.53 m) so small children cannot reach it, and away from all moving parts of the door.
6. Ensure that the warning tag supplied with the operator is properly fixed on the door and it is visible while the door is moving. (Figure 2)




Figure 2 Warning tag



WARNING

STAND CLEAR OF DOOR AND VERIFY THAT DOORWAY IS CLEAR, THEN PULL EMERGENCY RELEASE DISCONNECT LEVER TO DISCONNECT OPERATOR FOR MANUAL OPERATION OF DOOR

4.2 INSTALLATION OF MGT OPERATOR

IMPORTANT NOTE: THIS OPERATOR MUST BE INSTALLED A MINIMUM OF 8 FT (2.4 m) ABOVE FLOOR

Before the operator is installed, ensure that door has been properly aligned and is working smoothly. It is advisable to assemble the operator to the trolley tracks on the floor prior to installation.

1. Bolt the tracks to the operator using bolts provided (Figure 3).




Figure 3 Assembling operator and tracks

2. Place carriage on rails and slide to forward position, making sure that the chain take-up bolt is facing the operator (Figure 4).




Figure 4 Inserting carriage in tracks

3. Attach front idler and rail spreaders as shown in Figure 5.




Figure 5 Front idler and spreaders

4. Attach one end of the chain to the carriage using a chain link (Figure 6). Run chain around front idler and continue around drive sprocket on operator. Then fix second end of the chain using another chain link to the take-up bolt and fix the take-up bolt to the carriage. Chain could then be tightened by adjusting the take-up bolts in carriage. Properly adjusted chain should sag approximately 2" (5 cm) at halfway point on tracks




Figure 6 Installing chain

Note: All trolley operators are designed to mount directly over the center of the door, and the operator tracks should clear the door by approximately 2.5" (6.4 cm). If it is not possible to mount the operator exactly centered, it is possible to install it slightly off center for torsion spring doors.

5. Establish center line of door by measuring door width and marking a vertical line on the wall directly above the door.
6. Open the door manually to determine the high arc (highest point) of door travel (see Figure 7). Using a carpenter's level draw a line so that it will intersect with the vertical line determined earlier.




Figure 7 Highest arc of travel

7. The wall mounting bracket has three bolt holes for mounting the front end of the trolley tracks. The bracket should be attached to the wall with these holes 2.5" (6.4cm) above the high arc of door (Figure 8). Wood blocking or angle iron framework may be installed on the wall to provide for the attachment of the front bracket.




Figure 8 Wall mount bracket

8. After securing the wall mounting bracket, allow the motor to rest on floor and raise the front end of the rails and secure (but not tighten) with 5/16" bolts and nuts (Figure 9). If torsion hardware is preventing the rails from lining up with the wall bracket, secure temporarily with cord.




Figure 9 Installing tracks on wall bracket

9. Hoist rear of operator using block & fall or other suitable means above level of horizontal door tracks and temporarily secure in place using rope or chain. Tighten front end bracket bolts.
10. Carefully open door by hand and move rear of operator so that it is directly over center of door, with approximately 3" clearance between door and bottom of operator rails (Figure 10).




Figure 10 Adjusting height of operator

11. Hanging brackets may now be affixed from ceiling to operator (Figure 11). Two or more holes are provided in frame of operator for this purpose. Take care that unit remains centered over door during installation of hanger brackets. After vertical drops are made and secured, side braces should be installed.
12. Approximately 5 feet (1.5 m) from forward end of rails, locate set of 3/8" holes for angle iron braces to secure rails. Two drops pieces should be installed at this point to further strengthen installation (Figure 11).




Figure 11 Location and installation of hangers and side braces

13. Close door. Connect door arm to carriage using $3/8" \times 2-1/4"$ bolt furnished. Fasten door bracket to arm and position on door as shown in Figure 12. Mount door bracket to center of door in such a way that the door bracket is also in line with the top rollers on the door.




Figure 12 Installing door arm to door

14. Door arm should always lean vertical (Figure 13).




Figure 13 Position of door arm

4.3 CLUTCH ADJUSTMENT

1. Loosen clutch set screws (Figure 14 A).
2. Back off clutch nut until there is insufficient tension on clutch spring to permit clutch to drive door (Figure 24 B).
3. Tighten clutch nut gradually until there is just enough tension on spring to permit operator to move door smoothly, but allow clutch to slip if door is obstructed.
4. When clutch is properly adjusted it should be possible to stop door by hand during travel.
5. Be sure to tighten clutch set screws each time operator is tested for clutch adjustment and that it is locked in place on completion of adjustments.



WARNING

THE FRICTION CLUTCH IS DESIGNED TO PROTECT VEHICLES AND DOOR HARDWARE AGAINST DAMAGE. IT IS NOT INTENDED TO PROTECT PEOPLE. ALL DOORS SERVING PERSONNEL ARE TO BE FITTED WITH AN APPROPRIATE REVERSING DEVICE OR REVERSING EDGE TO PREVENT INJURY OR DEATH. If an automatic reversing device is desired, several types are available as accessories. Consult your dealer for a recommendation.




Figure 14 Reducer adjustment

BRAKE ADJUSTMENT

- The brake is factory set. However, after extensive use the brake may need to be adjusted.
- In order to obtain best performance and maximum life, the brake must be adjusted for:
 - Proper clearance between the brake band and the brake drum when the solenoid is energized.
 - Correct brake tensioning when the solenoid is de-energized.

TO ADJUST THE BRAKE SYSTEM:

1. Remove the solenoid cover.
2. Slightly unscrew the pivot nut (Figure 15)
3. To adjust the brake band tension, move the adjustment lever. To increase tension, move the lever away from the motor. To decrease tension, move the lever toward the motor
4. Tighten the pivot nut
5. Check clearance but manually holding the solenoid plunger. The brake drum should rotate easily by hand.
6. After adjustment is done, re-install the solenoid cover.




Figure 15 Brake system

4.4 ADJUSTMENT OF LIMIT SWITCHES

1. Open the cover of the electrical enclosure.




Figure 16 Adjusting the limit cams

Note: Turning the cam towards the center on the limit shaft increases door travel.
Turning the cam towards the limit switch decreases door travel.

- Open limit switch adjustment:
 2. Manually raise the door to a nearly opened position or desired open position.
 3. Depress the cams-retaining bracket from the Open side and rotate manually the Open cam (*Figure 16*) until the cam activates the limit switches sufficiently so as to hear the switches click (2 clicks for hardwired circuit. Only one click with ECB and check if the OPEN limit light is ON).
 4. Release cam-retaining bracket and make sure that the bracket engages in the slots of both cams.
 - Close limit switch adjustment:
 5. Manually lower the door to a nearly to 6" above the ground.
 6. Depress the cams-retaining bracket from the Close side and rotate manually the Close cam (*Figure 16*) until the cam activates the Close limit switch sufficiently so as to hear the switch click (2 clicks for hardwired circuit. Only one click with ECB and check if the CLOSE limit light is ON).
 - Testing door electrically:
 7. Upon completion of all wiring connections, use the wall push buttons (or on board buttons for ECB), to run the door electrically and check if it is stopping properly to fully open and fully close positions.
 - Fine adjustment:

If door is not opening or closing properly or if there is a gap between the door and floor, re-adjust the close limit switch. **Note:** One (1) on cam is equal to about ½" on the door travel.

For close position: Adjust one notch at a time until the close limit switch is properly adjusted and the door stop smoothly on closed position.
8. Close the control box once the limit switches are adjusted.

4.5 MINIMUM SUGGESTED WIRE SIZE FOR CONTROL CIRCUIT

The control circuit operates at 24 VAC. Due to the resistance in the wire used to carry the control circuit voltage, it is important to use the appropriate wire size with respect to the distance between the operator and the push-button station.

Below is a chart (TABLE 2) indicating the minimum recommended wire size with respect to the total distance between the operator and the push-button station. DO NOT exceed the maximum distance. If there are several push-button stations in series you must ADD all these distances before selecting the appropriate wire gauge for your operator.

If the wire gauge is not suitable for the distance, problems in operation will be encountered such as chattering relays and contactor, premature wear of the contacts and possible tripping of the motor's thermal protection.

If a greater distance is required, a long distance interface module is suggested (consult factory).

When large gauge wire is used, a separate junction box will be needed for operator power connection (not supplied).

All power wiring to the operator should be installed by a qualified electrician and may vary with respect to conduit size and type as specified in the National Electrical Code, Article 430, allowing 5% voltage drop. Power must also be connected in accordance with local codes.

TABLE 2 WIRE SIZE vs. DISTANCE

24 VAC CONTROL WIRING	
Minimum suggested Wire gauge (AWG)	Maximum distance between operator and all Push-button stations feet (meters)
22	50 (15)
20	100 (30)
18	150 (45)
16	250 (75)
14	350 (105)
12	450 (135)

5. SCHEDULED MAINTENANCE

Inspection and service should be performed anytime a malfunction is observed or suspected.

 WARNING WHEN SERVICING - ALWAYS DISCONNECT OPERATOR FROM POWER SUPPLY

5.1. MECHANICAL

- The door area should always be kept clear of dirt, rocks or any other substance to insure proper operation.


EVERY 3 MONTHS	<ul style="list-style-type: none"> - Check and adjust the brake band and the solenoid, if needed. - Check and adjust the clutch, if necessary. - Check all safety features, if responding properly (photocells, pneumatic etc)
EVERY 6 MONTHS	<ul style="list-style-type: none"> - Check the oil level in the gearbox. - Lubricate all moving parts, bushings are oil impregnated and are lubricated for life. - Verify that all mechanical parts function properly. - Inspect the V-belt and adjust or replace if necessary. - Manually operate the door. If the door does not open or close freely, correct the cause of the malfunction.
ONCE A YEAR	<ul style="list-style-type: none"> - Inspect all bolts and screws and tighten if necessary. - Check for any excessive slack in chains and adjust or replace them if necessary. The limit switches may have to be reset after a chain adjustment. - Inspect the door for wear and damage. - Run the operator a few cycles: <ul style="list-style-type: none"> Make sure that the door rollers are rolling smoothly on the track. Listen to the motor: The motor should hum quietly and smoothly. Verify that the limit operates quietly and smoothly: investigate any unusual noise. - Verify that the mooring bolts are holding the unit securely. - Inspect the unit for evidence of corrosion.

5.2. ELECTRICAL

 WARNING BEFORE OPENING THE CONTROL BOX COVER, DISCONNECT OPERATOR FROM POWER SUPPLY

- Inspect the wiring compartment and remove any dirt from the control units.
- Verify all the grounding wires and terminations for corrosion. Be particularly careful to check the ground wires.
- Check the terminal strip to insure that all the screws are tight.
- Verify that the security systems installed on the operator are fully operational.
- Verify the voltage at the input terminals while the operator is running. The voltage must not drop more than 10% momentarily. If the voltage drop is too deep when running, the relays may chatter, the contact points will wear prematurely and may eventually weld. Verify the power terminations for corrosion.
- Verify the current consumption of the unit with an amp-meter. The value of current should be consistent with the nameplate specifications. Investigate any anomaly.

6. MGT exploded view



185	4	LIMIT SWITCH SPACER	SPACEFOOT	1	4
186	2	KEY 1/4 X 1/4 X 1 1/2	KW019	1	4
187	1	CHAIN LINK	LINK011	1	4
188	1	KW 3/16 X 3/16 X 1.5 C/W MOTOR		2	1
189	1	KW 3/16 X 3/16 X 1.5 C/W REDU		3	1
190	1	KW 1/4 X 1/4 X 3 C/W REDUCER		4	1
191	1	KW 1/4 X 1/4 X 3 C/W REDUCER		5	1

#	QTY	DESCRIPTION	#MANARKS	REV
1	1	MGT FRAME	FRAM023	B
2	1	MGT FRAME BODY	FRAM010	F
3	1	CONTR. BOX COVER	COBOX01	H
4	1	CONTR. BOX COVER	COBOX01	G
5	1	CONTR. BOX COVER	COBOX01	E
6	1	LIMIT SWITCH LEVER	LENSW02	B
7	1	COMPULTE	CAMPUL001	E
8	1	LIMIT SHAFT	SHAFT105	E
9	1	MGT MSLMTH LTRBH DRIVE	SHAFTR08	E
10	1	TERMINAL STRIP SUPPORT	BRCKCT136	C
11	2	LIMIT CAMS	CAM004	C
12	1	ADJUSTMENT BRK LEVER	BRCKCT013	F
13	1	ADJUSTMENT BRK LEVER	LEVER052	A
14	1	STEEL EUSHING	LEVER051	E
15	1	STEEL EUSHING	BUSHING053	C
16	1	BRK DRUM	DRUM004	C
17	1	BRK BAND	BRKE PART017	..
50	1	MOTOR	MOTOR	..
51	1	REDUCER 4.01 C/W CLUTCH	REDUCER028	..
52	1	9 TOOTH 410 SPROCKET	SPR410B9X 625	..
53	1	15 TOOTH 41 SPROCKET	SPR415B1X1	..
54	1	15 TOOTH 41 SPROCKET	SPR415B1X1	..
55	1	12 TOOTH 41 SPROCKET	SPR412B1X1	..
56	1	SPR410B1BXT KI/4 255	SPR410B1BXT	..
57	2	FLANGED BEARING 625	BEARING005	..
58	2	FLANGED BEARING 1"	BEARING007	..
59	1	ROLLER CHAIN 410
60	2	1" COLLAR	RELAY026	..
100	1	2 POLE RELAY 120V	RELAY024	..
101	1	2 POLE RELAY 24V	LIMIT015	A
102	4	LIMIT SWITCH	LIMIT01	..
103	1	LIMIT SWITCH	LIMIT01	..
104	1	SOLID END PEGAL TERMINAL STRIP	TERMIN005	..
105	1	CONDUCTOR KLEN BRADLET	CONTRAS03	..
106	1	TRANSFORMER	FUSE017	..
107	1	FUSE HOLDER	FUSE017	..
108	1	FUSE 2 AMP.	FUSE006	..
109	1	FUSE 2 AMP.	RESET	..
110	1	RESET	RESET	..
111	1	TERMINAL STRIP	TSRIP001	..
112	1	GROUND LUG	CONNECTOR039	..
150	4	HEX HD BOLT 1/4-20UNC X 3/4	BOLT002	..
151	3	HEX HD BOLT 1/4-20UNC X 1 1/2	BOLT008	..
153	4	HEX HD BOLT 3/8-16UNC X 1 1/4	BOLT006	..
154	4	HEX HD BOLT 3/8-16UNC X 1 1/4	BOLT007	..
155	1	CARRIAGE BOLT 1/4 X 1 1/4	BOLT083	..
156	6	HEX NUT 6-32UNC	NUT002	..
157	2	HEX NUT 6-32UNC	NUT003	..
158	2	HEX NUT 6-32UNC	NUT010	..
159	4	HEX NUT 3/8-16UNC	NUT011	..
160	2	LOCK NUT 5/8-24UNEF	NUT015	..
161	6	LOCK NUT 6-32UNC	NUT018	..
162	1	LOCK NUT 1/4-20UNC	NUT019	..
163	3	LOCK NUT 1/4-20UNC	NUT028	..
165	9	SET SCREW 1/4-20UNC X 1/4	SCREW002	..
166	5	SET SCREW 5/16-18UNC X 5/16	SCREW003	..
170	12	SELF TAPPING SCREW 6-32X5/8 F	SCREW004	..
171	6	SELF TAPPING SCREW 6/32X5/8 F	SCREW005	..
172	10	SELF TAPPING SCREW #10 X 3/8	SCREW022	..
173	6	ROUND HD SCREW 6-32UNC X 2	SCREW045	..
174	2	ROUND HD SCREW 8-32UNC X 3/8	SCREW049	..
175	2	ROUND HD SCREW 8-32UNC X 3/2	SCREW054	..
176	4	FLAT WASHER 25 X 5/8 X .049	WASHER010	..
177	4	FLAT WASHER 438 X 1 X .083	WASHER024	..
178	2	LOCK WASHER # 8	WASHER026	..
179	4	LOCK WASHER 1/4	WASHER030	..
181	8	LOCK WASHER 3/8	WASHER031	..
182	2	SPRING C-260-Q47-1060	SPRING001	..
183	1	E-312-42-1900	SPRING026	..
184	1	COITER PIN 1/8 X 3	PIN002	..

THE INFORMATION CONTAINED HEREIN IS PROPRIETARY TO MANARKS AND SHALL NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM.

MANARKS PMA DRIVE
 POINT-CLARE, QC H9R 1A8
 TEL.: 514-426-1332
 FAX: 514-426-4330



7. Specific section for operators supplied with

ELECTRONIC CONTROL BOARD

7.1 POWER AND CONTROL WIRING DIAGRAM

7.2 ELECTRONIC CIRCUIT BOARD

7.3 PROGRAM SETTING

7.4 MODE SETTING


7.5 CONNECTION OF REVERSING EDGE

7.6 DOOR INTERLOCK & FRICTION CLUTCH

7.9 TROUBLESHOOTING GUIDE

NOTE: Please refer to page 27 for hardwired operators.

7.1 POWER AND CONTROL WIRING DIAGRAM



VERY IMPORTANT NOTES


⚠ Before installing power and control wiring, be sure to follow all specifications described below. Failure to do so may damage the operator.

- The operator must be properly grounded and connected in accordance to local electrical codes.
- Use different knockouts available on EACH side of the control box to pass the power and control wiring through.
- **Ensure maximum separation between power wiring and low voltage control wirings in the control box.**
- Please refer to next page for details.



- If a push button is not used, a jumper must be placed between #8 & #9
****Under this condition a stop command is not available to stop the door during its travel.*
- Please refer to Accessories Wiring diagrams (TN005E) before connecting any external accessories
- **2 Amp fuse** is used to protect 24VDC on electronic board and also the 24VAC supply for auxiliary control devices


LOW VOLTAGE (controls) AND HIGH VOLTAGE (power) WIRINGS.





! WARNING

- Wall control(s) must be located so that the door is within sight of the user.
- If momentary contact (B2 mode) is used, an external reversing device must be install.

Accessory Wiring





7.2 ELECTRONIC CONTROL BOARD

LED MONITORING STATUS

LED's on the ECB help will wiring and making troubleshooting diagnoses. Every LED states the actual position of the door. The board has a non-volatile memory and all the LED return to their initial state after a power

L.E.D	Color	Status
+24 V	Green	When ON indicates the presence of 24VDC on the Logic Board
+5 V	Green	When ON indicates the presence of 5VDC power in the Control Circuit
Open Limit	Red	When ON indicates door position, completely open.
Open	Red	Only when the open relay is activated (open relay is energized)
Close Limit	Red	When ON indicates door position, completely close.
Close	Red	Only when the close relay is activated (close relay is energized)
Safe	Red	Light ON only when safety devices are activated.
INDICATOR	Red	Flashes only when motor runs in opposite direction and activates the wrong limit switch.
		Stay ON only when the "centrifugal switch" is opened (<i>please contact technical support</i>)
STOP	Yellow	In normal conditions light; stay ON, goes OFF every time when press STOP button or hoist is engaged

interruption.

Stop LED OFF:

- Check if the Stop button is properly connected on #8 and #9 or if a Normally Closed contact is used.
- Verify if the Hoist is properly engaged and if the Hoist switch is closed (or if any external interlock device is remained open)

EXTERNAL CONTROLS

Refer to the wiring diagram on page 16 before connecting power or any external device to the ECB. Neglecting to use the proper terminals will result in complete damage to the ECB. If you are not certain about procedures, please consult Manaras for assistance.

NOTE: Do not attempt correction by reversing wires on control station.



WARNING

WHEN REPLACING AN ELECTRONIC CONTROL BOARD DO CHECK THAT ALL JUMPERS ARE POSITIONED AS INDICATED IN THE WIRING DIAGRAMS ON PAGE 23 FOR SINGLE PHASE AND ON PAGE 24 FOR 3-PHASE.

- **Program and Program settings**





Programming ability and door control at electrical box are provided by Open/Close/Stop buttons and Rotary Switch located on the ECB.

- **Programs**







PROGRAMS	FUNCTIONS AND DESCRIPTIONS
RUN TIMER	The Run Timer stops automatically the operator after an adjustable time delay either travelling upwards or downwards. The Run Timer is designed to protect the door and the operator by preventing the motor over running much longer than the normal time.
MID-STOP	Mid-Stop function will, when active, move the door from the down position to a predetermined Mid-stop position when the open button or Open/Close device is activated. Once at Mid-Stop, subsequent Open/close commands will close the door. To move the door to full open position, the open button must be pressed again.
TIMER TO CLOSE	Timer to Close is a function that, when active, will close the door after an adjustable time delay once the door has reached its fully open and mid-stop position. The timer to close function works only in T and TS modes.
TIMER TO CLOSE (from fully open position only)	Option used in conjunction with MID STOP function. When activated, Timer to Close is active from the fully open position only and not from the mid-stop position.
ADVANCE CLOSED TIME	“Advance close limit switch” is not needed with this feature. Advance close time will disable the reversing device once the close limit switch is activated and will stop the door after 200 milliseconds before it reaches the fully closed position. <i>Note: Door distance traveled within these 200 milliseconds may vary depending on the door speed.</i>

7.3 Program setting

Door should be in fully closed position while setting of these following programs .

PROGRAM SETTING			
PROGRAMS	ACTIVATE	DEACTIVATE	SELECT SWITCH
RUN TIMER	<ul style="list-style-type: none"> • Check if close limit switch is activated. • Set select switch on D. • Press “Open” button to add 10 sec to the total time needed to open the door. • Set the select switch on run mode (0, 1, 2, 3, 4 or 5). 	<ul style="list-style-type: none"> • Set select switch on D. • Press “Stop” button. • Set the select switch on run mode (0, 1, 2, 3, 4 or 5). 	
MID-STOP	<ul style="list-style-type: none"> • Check if the close limit is activated. • Set select switch on “C” • Press “Open” button then press “Stop” button on desired Mid-Stop position. • Set the select switch back on run mode (0, 1, 4 or 5). 	<ul style="list-style-type: none"> • Set select switch on “C”. • Press “Stop”, “Close” and “Open” buttons consecutively. • Set the select switch back on run mode (0, 1, 4 or 5). 	
TIMER TO CLOSE	<ul style="list-style-type: none"> • Set select switch on “B”. • Press “Open” button to add 15 sec or “Close” button to add 1 sec each time (max. 4 minutes & 15 seconds). • Set the select switch on T or TS mode. 	<ul style="list-style-type: none"> • Set select switch on “B”. • Press “Stop” button the timer to close is reset to 0 sec but still activated. • To deactivate the timer to close completely set the switch on desired position (0, 1, 2 or 3). 	
TIMER TO CLOSE (from fully open position only)	<ul style="list-style-type: none"> • Set select switch on “6”. • First press the “Close” button and then the “Stop” button. • Set the select switch on T or TS mode. 	<ul style="list-style-type: none"> • Set select switch on “6”. • Press “Close” button. • Set the select switch on T or TS mode. <p>*Now the Timer to Close works from fully Open and Mid-Stop positions.</p>	
Controlling Timer to Close from floor level (using wall buttons)			
While door is in closed position, by pressing “Stop” 3 times and “Close” 3 times consecutively on the push button station, the timer to close is deactivated (<i>timer to close is suspended</i>).		Timer to close is re-activated (<i>timer to close is back to normal function</i>) simply when door is closed either from fully open or from mid-stop positions.	

7.4 MODE SETTING

Wiring Type	Wiring Type & Functions	Select Switch
C2 (factory preset)	Set select switch on 0 Momentary contact to open and stop, constant pressure to close with 3 buttons station. Activation of safety devices will reverse the door during closing. Auxiliary devices function as an Open control and to reverse door during closing.	
B2	Set the select switch on 1. Momentary contact to Open/Close and Stop with 3 buttons station. Activation of safety devices will reverse the door during closing. Auxiliary devices function as Open/Close control and reverse the door during closing.	
D1	Set the select switch on 2. Constant pressure to Open and constant pressure to Close. Activation of safety devices will stop the door during closing.	
E2	Set the select switch on 3 Momentary contact to open and constant pressure to Close. Release of Close button activates the door upwards. Activation of safety devices will reverse door motion to fully open position.	
T	Set the select switch on 4. Momentary contact to Open / Close and Stop. Timer to Close if programmed, safety devices reverse upon but will disable Timer to Close. Timer to close will also be disabled if there is a power outage, a chain hoist is engaged or the stop is pressed before elapsed time. The timer resumes its normal operation, once the close cycle is completed.	
TS	Set the select switch on 5. Momentary contact to Open / Close and Stop. Timer to Close if programmed, safety devices reverse upon activation and will refresh Timer to Close. Timer to close also gets refreshed, if there is a power outage, a chain hoist is engaged or a stop button is pressed before elapsed time.	

IMPORTANT NOTES:

- **STOP JUMPER**

- While testing the operator or adjusting the cams using the O/C/S buttons available on the Electronic Control Board, a jumper should be placed between the #8 & #9. Once the tests or adjustments completed the jumper should removed before connecting the wall 3-push buttons station. Failure to remove the stop jumper, **the STOP BUTTON WILL NOT RESPOND.**
- A stop jumper should be installed between #8 & #9 when using a key switch, a single button Radio control or a 2-buttons station (Open/Close). **IN THESE CONDITIONS NO STOP COMMAND IS AVAILABLE TO STOP THE DOOR DURING THE TRAVELLING.**

**WARNING**

MOTORIZED DOORS CAN CAUSE SEVERE INJURY OR DEATH. MANARAS STRONGLY RECOMMENDS THE USE OF ENTRAPMENT PROTECTION SYSTEMS, ESPECIALLY IN THE CASES OF MOMENTARY CONTACT TO CLOSE (B2 WIRING) AND TIMER TO CLOSE (T & TS).

7.5 CONNECTION OF A REVERSING EDGE DEVICE

IMPORTANT NOTE

IF THE DOOR IS CONTROLLED BY ANY DEVICE OTHER THAN A CONSTANT PRESSURE PUSH-BUTTON STATION, A REVERSING EDGE MUST BE CONNECTED.



CAUTION: CONNECT REVERSING DEVICE APPROPRIATE TO INSTALLATION.

Connection and installation of a reversing edge device is provided with the edge (Figure 17). Any such device that uses a normally open contact may be connected to terminals **3 and 5** on the low voltage terminal block. When the door comes in contact with an object during downward travel, the circuit will cause the motor to reverse the door to the fully open position. In addition, there is a cut-off limit switch (*advance close limit switch*) that will de-activate the reversing edge during the last few inches of the door's downward travel.




Figure 17 Reversing Edge

7.6 DOOR LOCK SENSOR & FRICTION CLUTCH

Please read carefully prior to installing this operator

All operators supplied with an electronic control board are equipped with the “DOOR LOCK SENSOR” feature

The DOOR LOCK SENSOR prevents any damage to the door when the door lock hasn't been removed prior to electronic operation. It eliminates the need of expensive external interlock wiring.

This feature can only be used on operators equipped with a FRICTION CLUTCH.

When the lock stops the door, the clutch slips and in less than 1 second, the door will reverse a fraction of a second to release the lock.



WARNING

IN ORDER NOT TO DAMAGE THE DOOR WHEN THE LOCK IS ON, THE FRICTION CLUTCH HAS TO BE ADJUSTED PROPERLY ACCORDING TO THE INSTRUCTIONS PROVIDED ON PAGE 11

7.7 LIMIT SWITCHES



WARNING

TO AVOID THE DANGER OF POSSIBLE DAMAGE TO THE DOOR AND OPERATOR, TRAVELLING CAMS MUST BE ADJUSTED TO THEIR APPROXIMATE POSITIONS BEFORE MANUALLY OPERATING THE DOOR OR BEFORE APPLYING POWER TO THE OPERATOR.

Only 2 limit switches are used in operators built with an Electronic Control Board. One for the "Open" side and one for the "Close" side. No advanced Open or Closed limit switches is used. The microprocessor with the built-in logic replaces the advanced Open and Closed limit switches (Figure 18).




Figure 18 Limit switches

7.8 DESCRIPTION LIMIT SWITCHES

- The "Open" limit switch is the end of travel in the open position. Adjust the cam so that the door stops in the open position at the desired location.
- The "Close" limit switch is the end in the close position. Adjust the cam so that the door stops in the closed position at the desired position.

7.9 TROUBLE SHOOTING AN OPERATOR WITH ECB

Troubleshooting an operator with an ECB is easier since the LEDs provided on the circuit board help to bring a better diagnostic while finding the faults.


Easy fix	Check the followings that may prevent the operator from starting before coming to any conclusion
Check light status on the ECB	Before starting any intervention, check the LEDs status and refer to the page 17 for a proper diagnostic.
Check the operating modes	Review the operating modes: B2, C2, D1, T or TS
Check the programming	A wrong programming on Timer to Close or Mid Stop will stop the door to an improper position.
Check the presence of stop jumper	If the 3 test buttons are being used without the stop jumper between #8 & #9, the operator will not respond to the 3 buttons command

TROUBLE SHOOTING GUIDE

SYMPTOM	PROBABLE CAUSE	SUGGESTED ACTION
Door will not respond to « open » or « close » push buttons	Check if STOP Led: if OFF.	
	Check if hoist is not engaged.	Disengage the hoist. (JP4 on 2-3 for trolley & sliding operators)
	Defective “stop” push button.	Replace.
	Check wiring from push button to operator	Replace if needed.
	Loose connection in one of the push buttons.	Verify, tighten or replace
	If STOP Led is ON.	
	Defective “open” or “close” push button.	Replace.
Door will not respond to “open” command, but will respond to “close” command	Check the “open” Led: if OFF	Replace the board
	If “open” Led is ON	
	Defective “open” push button	Replace.
	Defective “open” limit switch.	Replace.
	Loose wire on “open” push button, “open” limit switch.	Verify, tighten or replace.
Door won’t respond to “close” command, but will respond to “open” command	Check the “close” Led: if OFF	Replace the board
	If “close” Led is ON	
	Defective “close” push button.	Replace.
	Defective “close” limit switch.	Replace.
	Loose wire on close push-button, close limit switch.	Verify, tighten or replace.
Door move in wrong direction single or 3-phase operator	Motor rotation is reversed on board motor terminals.	Interchange #T13 and #T14 on the power board.
Stop button doesn’t stop the door	Two 3-push button stations connected in parallel.	Correct wiring (only stop buttons in series)
	Bad stop button.	Check and replace.
Sensing edge does not reverse door	Pneumatic hose broken.	Check and adjust.
	Bad air switch.	Check and adjust.
	Bad wiring.	Check and correct wiring.
When door closes it reverses to fully open after it hits the floor	The advanced close time is not proper adjusted.	Check and adjust.
	The close limit switch is not being engaged by traveling cam.	The close limit switch needs to be adjusted properly at the end of travel.
	An “open” command is given.	Check “open” push button or any opening device for short-circuit.
Motor hums, starts when spun (1 ph)	Capacitor defective.	Replace.
Motor relay buzz for a few seconds when door is stopped (1 ph)	Bleeder resistor faulty on capacitor.	Replace.
Motor fails to shut off at fully closed or opened position	Defective limit switch.	Operate limit switch manually while door is moving. If door does not stop, replace the switch.
	Limit cams are not adjusted.	Verify and adjust.
	Limit drive chain broken.	Replace.
	Loose sprocket on limit shaft.	Tighten setscrew.
	Limit shaft does not rotate.	Verify and replace accordingly.
Motor turns but door does not move	Sprocket key is missing.	Replace.
	Drive chain broken.	Replace.
	Limit shaft does not rotate.	Adjust clutch tension.
Limit switches do not hold their setting	Loose drive or limit chain allows chain to jump sprocket teeth.	Adjust chain to proper tension.
	Limit cam retainer not engaging slots in limit cams.	Be sure retainer is in slots of both cams.
	Limit cams are binding on shaft threads, which allow them to jump position on retainer.	Lubricate shaft threads. Limit cams should turn freely.
	Limit shaft have a light.	Verify and adjust.

7.10 Single phase ECB wiring diagram

WIRING DIAGRAM FOR 1-PHASE OPERATOR- MODEL : MGHMGTMSGLD



TO REVERSE MOTOR ROTATION WIRE ON T13 AND T14.

ROTARY SWITCH SETTINGS

WIRING TYPES	PROGRAM SETTINGS
0 C2	6 MID-STOP TIMER TO CLOSE
1 B2	7 ADV CLOSE TIME
2 D1	8 WARNING LIGHT TIMER
3 E2	B TIMER TO CLOSE
4 T	C MID-STOP
5 TS	D RUN TIMER

ON BOARD JUMPER SETTINGS

JP2	JP4
1, 2, 3	DISCONNECT
240VAC/1PH	PRESENT
1, 2	NOT PRESENT
2, 3	

WARNING LIGHT/RECEIVER MODULE
TBS CONNECTION FOR WARNING LIGHT AND RECEIVER MODULE (CONSULT FACTORY)

NOTE:-
FOR ROTARY SWITCH SETTINGS AND PROGRAMMING PROCEDURES, REFER TO INSTRUCTION MANUAL.

EXTERNAL WIRING

LINE POWER	24 VAC POWER	EXTERNAL INTERLOCK	SAFETY REVERSE	OPEN/CLOSE COMMAND	SINGLE PUSH-BUTTON STATION	TWO PUSH-BUTTON STATION	RADIO RECEIVER
L1,1 N1,2	1 2	10 11	3 5	3 4	9 8 7 6	6 7 8 9	7 8 9
POWER SUPPLY 1 Ph, 60 Hz.	24 VAC POWER MOTION DETECTOR AVAILABLE 10A MAX.	FACTORY INSTALLED JUMPER REMOVE IF EXT. INTERLOCK IS USED	CONTACT FOR SAFETY REVERSE DEVICE	CONTACT FOR OPEN/CLOSE DEVICE	NOTE PLACE A JUMPER BETWEEN TERMINALS 8 AND 9. IF STOP BUTTON IS NOT USED.	P.B. SH1 P.B. SH2	RADIO CONTROL TERMINAL STRIP

ATTENTION- USE 18AWG OR HIGHER FOR WIRING ALL EXTERNAL CONNECTIONS


THE INFORMATION CONTAINED HEREIN IS PROPRIETARY TO MANARAS OPERA AND SHALL NOT BE REPRODUCED OR DISCLOSED OR USED FOR ANY DESIGN OR MANUFACTURE EXCEPT WHEN USER POSSESSES DIRECT WRITTEN AUTHORIZATION FROM MANARAS OPERA.

WIRING DIAGRAM, 120/208/220VAC, 1-PHASE

DRAWN BY: BP
DATE: 15 NOV 2006
REV DATE: 13 FEB 2007


MANARAS OPERA 91-740-0720 QUEBEC INC.
158 ONENIDA DRIVE
TONTONOLA, IL 61889
PHONE: 1-888-444-8888
FAX: 1-888-626-0608

7.11 3-Phase ECB wiring diagram









WIRING DIAGRAM FOR 3-PHASE OPERATOR, MODEL : MGHMGT/MGSLD

EXTERNAL WIRING



ROTARY SWITCH SETTINGS	
WIRING TYPES	PROGRAM SETTINGS



ON BOARD JUMPER SETTINGS	
TS	JP2
5	1, 2, 3
4	2, 3
3	1, 2, 3
2	1, 2, 3
1	1, 2, 3
0	1, 2, 3

WARNING LIGHT/RECEIVER MODULE

CONNECTION FOR WARNING LIGHT AND RECEIVER MODULE (CONSULT FACTORY)

NOTE:-
FOR ROTARY SWITCH SETTINGS AND PROGRAMMING PROCEDURES, REFER TO INSTRUCTION MANUAL.

THE INFORMATION CONTAINED HEREIN IS PROPRIETARY TO MANARAS/OPERA AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM. PERMISSION IS GRANTED TO MANUFACTURE EXCEPT WHEN USER POSSESSES DIRECT WRITTEN AUTHORIZATION FROM MANARAS/OPERA.

TITLE: WIRING DIAGRAM, 208/460/575VAC, 3-PHASE

DATE: 15 NOV 2008

DRAWN BY: BP

DATE: 13 FEB 2007

REV: A

MANARAS/OPERA 9140-0720 QUEBEC INC.

136 ONEIDA DRIVE

POINTE-CLAIRE, QC H9R 1A8

TEL: 1-800-361-2260

FAX: 1-888-628-0006





8. Single Button Control Radio (SBC) & Warning lights programming instructions.

8.1 Single button Radio Programming Instructions

With the single button radio feature, it is now possible to use a single channel transmitter as a Commercial application and as well as Single Button Radio Control (SBC).

The SBC give the possibility to open, stop or close the door by using a single button radio transmitter (or a single push button station). This feature is available on operators equipped with Electronic Control Board (BOARD060 with program from MP4.8).

Setting of Single Button Radio Control Sequence (SBC)		
Activating and deactivating a Single Button Radio Control.		
Activating SBC sequence: Set select switch on 9 and press Open (INDICATOR LED should light ON)		
- Then set the select switch on B2 (1), T (4) and TS (5) mode.		
Deactivating SBC sequence: Set select switch on 9 and press Stop. (INDICATOR LED should light ON)		
- The radio receiver is back for Standard Commercial Sequence. - Set the select switch to desired position (0, 1, 2, 3, 4 or 5).		
Operating sequence of Single Button Radio control.		
Door operating sequence (ex. door fully closed)		Single button radio
Activation	Door reaction	
1st	Will open	
2nd	Will stop	
3rd	Will close	
4th	Will stop	

Note:

- While using the radio control in SBC mode, a moving door will stop upon activation of a single button transmitter.
- When door is in partially opened position (not moving), pushing the single button transmitter will open the door if the last movement of the door was closing or will close the door if the last movement was opening.
- If the door is partially opened (not moving) for more than two minutes, activating the single button transmitter will always open the door.
- In case of Timer to Close: Mode 4 (T) or 5 (TS).
- Activating the single push transmitter will close the door immediately from fully opened position even the time is not expired yet.
- At power ON, the single push button transmitter will always open the door upon activation.

8.2 Warning Light Sequence


Lights	Operating sequence
Red	The light is solid red when the door is closing and opening. Light turns OFF once the door reaches the fully open or fully closed position
Green	The green light is ON only when the door is fully open and stays ON during a preset time (programmed by the Timer to Close)
Red (flashing)	The red light starts flashing once the green light is OFF and when the door is about to close. This is to warn the users that the door will close shortly. It stops flashing once the door start closing.
Warning lights sequence is operational from Mid-Point position in same way as from fully open	

8.3 Programming warning lights sequence (door should be in the closed position)

NOTE: Warning lights is functional only with Timer to Close

SETTING	ACTIVATE	DEACTIVATE	SELECT SWITCH
TIMER TO CLOSE	<ul style="list-style-type: none"> Set select switch on "B" Press "Open" button to add 15 sec or "Close" button to add 1 sec each time (max. 4 minutes & 30 seconds) Set the select switch on 4 (T) or 5 (TS) mode 	<ul style="list-style-type: none"> Set select switch on "B" Press "Stop" button the timer to close is reset to 0 sec but still is activated. To deactivate the timer to close completely set the switch on desired position (0, 1, 2 or 3) 	
DEFAULT TIME SETTING 5 SEC			
RED LIGHTS (Flashing Time)	<ul style="list-style-type: none"> Set select switch on "8" Press "Open" to add 1 sec each time to a maximum of 15 sec. Press "Close" to deduct 1 sec each time to a minimum of 0 sec. Press "Stop" to bring the flashing time to 5 sec by default 	<ul style="list-style-type: none"> Set select switch on "8" and press "Close" to bring the flashing time to 0 sec. Or set the select switch to desired position (0, 1, 2 or 3) 	
Bring back select switch on T (4) or TS (5)			

8.4 Connection of Red and Green warning lights (If Warning Lights Module is sold separately)



9. Specific section for operators supplied with

ELECTROMECHANICAL CIRCUIT (Contactor Circuit)

- 9.1 WIRING OF MGT
- 9.2 B2/C2 WIRING
- 9.3 OPTIONAL CONTROL ACCESSORIES
- 9.4 CONNECTION OF REVERSING EDGE
- 9.5 LIMIT SWITCHES
- 9.6 OPERATOR START-UP AND START
- 9.7 TROUBLESHOOTING GUIDE

NOTE: Please refer to page 15 for hardwired operators.

9.1 WIRING OF THE MGT OPERATOR

Do NOT connect any accessory controls until the limit switch adjustments have been completed and the operator is functioning properly.

Refer to the electrical diagrams on pages 38 and 39 and to the accessory wiring diagrams on page 32 and 33.



WARNING

EXERCISE CAUTION WHEN OPERATING MACHINE. THE DRIVE CHAIN AND LIMIT CHAIN, WHEN EXPOSED AND TURNING, COULD CAUSE SEVERE INJURY.

NOTE: Wiring diagrams are glued on the inside the control box cover. If the diagram is faded or damaged, call the factory for a replacement. **DO NOT INSTALL ANY WIRING OR ATTEMPT TO RUN THIS OPERATOR WITHOUT CONSULTING THE WIRING DIAGRAM.**

Main Power Supply

Power to the operator is of the permanent connection type. Connect according to local electrical code. Ground the unit using the ground lug inside the control box.

- For single phase operators, connect the power supply to terminals L (line) and N (neutral) on the main terminal strip.
- For three phase operators, connect the power supply to terminals L1, L2 and L3 on the main terminal strip.




Figure 19 Power supply connection



WARNING

GROUND THE UNIT CORRECTLY USING THE COPPER GROUND LUG LOCATED INSIDE THE OPERATOR CONTROL BOX.

NOTE: All other connections on the terminal strip (1 to 9) are low voltage class II 24 VAC.

1. External interlock between terminals 1 and 2. A jumper is factory installed between these two terminals. If an external interlock is used (such as interlocking between two doors), remove the jumper between 1 and 2 and wire the interlock between these two terminals.




Figure 20 External interlock

2. A 3 button push-button station (open/close/stop) can be wired to terminals 2, 3, 4 and 5. Two push-button stations can be wired to these same terminals by following the wiring diagrams on pages 38 and 39.





Figure 21 Three button push-button station

3. Three terminals are provided for the wiring of a radio-control receiver. Terminal #9 is Ground, #7 is 24 VAC (common) and #8 is the relay contact provided by the radio-control receiver to activate the door to open or close. Furthermore, terminals 7, 8 and 9 are doubly available on the terminal strip inside and on a separate small terminal strip located on the side of the unit. This terminal makes it convenient to wire-up a standard single button radio receiver on the side of the unit. When the transmitter is activated, the door will open to the fully open position. From the fully open position, the door will close. If transmitter is activated while closing, the door will reverse to the fully open position.


NOTE: It may be required to reverse connections to 7 and 9 for other types of radio receivers (Allstar, Linear, Pulsar ...).



NOTE: (select B2)
Radio Control = B2 wiring
 Momentary contact to open, close and stop with a 3 buttons station.

Figure 22 Radio-control

A single button open/close door device can be wired to terminals 7 and 8 to behave in the same way as the radio control receiver.



NOTE: (select B2)
Open/Close = Radio Control
 Momentary contact to open and close with single button station.

Figure 23 Single button device

NOTE: If several control devices are to be used, connect one and check for proper operation before connecting the next device.

4. A reversing edge can be wired up to terminals 3 and 6. These terminals can also be used for any other reversing devices such as loop detectors and photocells.






Figure 24 Reversing edge or other device

IMPORTANT: Upon completion of all wiring connections, readjust limits as mentioned in section 4.4 using "Open", "Close" and "Stop" buttons.

9.2 Accessory Wiring










PHOTO051



White

PHOTO008




Interface Module Jumper (TK8200)


Always set the jumper located inside the Interface Module on N.O. (Normally Open)



FOR MOMENTARY CONTACT TO CLOSE (B2 WIRING), PLEASE REFER TO INSTRUCTION BELOW



C2



B2

C2 wiring: momentary contact to open and stop, constant pressure to close with 3 push button station. Activation of safety device will reverse the door during closing. Auxiliary devices to function as an open/control and to reverse the door during closing.

C2 to B2
Move red wire from #5 to #7

B2 wiring: momentary contact to open, close and stop with 3 push button station. Activation of safety device will reverse the door during closing. Auxiliary devices to function as an open/close control and to reverse the door during closing.

B2 to C2
Move red wire from #7 to #5

! WARNING
Motorized doors can cause serious injuries or death. Manaras strongly recommends the use of entrapment protection systems, especially in the case of momentary contact to close such as with B2 wiring or timer to close.

! WARNING

- Wall control(s) must be located so that the door is within sight of the user.
- If momentary contact (B2 mode) is used, an external reversing device must be install.

CONNECTION OF A REVERSING EDGE DEVICE

IMPORTANT NOTE: IF THE DOOR IS CONTROLLED BY ANY DEVICE OTHER THAN A CONSTANT PRESSURE PUSH-BUTTON STATION, A REVERSING EDGE MUST BE CONNECTED.



CAUTION: CONNECT REVERSING DEVICE APPROPRIATE TO INSTALLATION.

Connection and installation of a reversing edge device is provided with the edge (see also Figure 25). Any such device that uses a normally open contact may be connected to terminals **3 and 6** on the low voltage terminal block (Figure 24). When the door comes in contact with an object during downward travel, the circuit will cause the motor to reverse the door to the fully open position. In addition, there is a cut-off limit switch (*advanced close limit switch*) that will de-activate the reversing edge during the last few inches of the door's downward travel.




Figure 25 Reversing Edge

9.3 LIMIT SWITCHES



WARNING

TO AVOID THE DANGER OF POSSIBLE DAMAGE TO THE DOOR AND OPERATOR, LIMIT SWITCHES MUST BE ADJUSTED TO THEIR APPROXIMATE POSITIONS BEFORE MANUALLY OPERATING THE DOOR OR BEFORE APPLYING POWER TO THE OPERATOR.




Figure 26 Limit switches

- There are 4 limit switches. Two are used as end of travel, one is for radio-control or one-button operation and one is for reversing devices. These switches are activated by the rotary cams travelling on a threaded shaft (Figure 26)
- The Open limit switch is the end of travel in the open position. Adjust the cam so that the door stops in the open position at the desired location.
- The Advanced Open limit switch is used for radio-control and for a one-button (open/close) feature. This limit switch is set to be activated slightly before the "Open" limit switch when opening.
- The Close limit switch is the end of travel in the closed position. Adjust the cam so that the door stops in the closed position at the desired location.
- The Advanced Close limit switch is used in the operation of the reversing edge or other reversing devices. This limit switch deactivates any reversing devices slightly before the door reaches its closed position to prevent the door from reversing when fully closed.

9.4 MANUAL OPERATION OF MGT OPERATOR

The MGT operator is equipped with trolley release disconnect mechanism to operate the door manually, if necessary. To manually operate the door:

1. Pull the disconnect chain downwards and disconnect trolley arm from carriage (Figure 27)



WARNING

DOOR ARM IS RELEASED FROM TROLLEY CARRIAGE WHEN DISCONNECT CHAIN IS PULLED. TO AVOID BEING STRUCK BY DOOR ARM, DO NOT STAND DIRECTLY UNDER DOOR ARM WHEN PULLING CHAIN.

2. Operate the door manually (by hand).
3. To return to electrical operation merely re-attach trolley arm to carriage by pulling on trolley disconnect chain while re-inserting arm onto carriage (Figure 27). **Do not attempt to disengage the door while the operator is running or do not attempt to manually force a malfunctioning door to open or close.**




Figure 27 Disconnecting arm from carriage



DANGER

WHILE PERFORMING THE TESTS LISTED BELOW, IT'S VERY IMPORTANT TO HAVE A POWER SHUT-OFF DEVICE OR SOMEONE NEAR BY TO TURN THE POWER OFF WHEN NEEDED

9.5 OPERATOR START-UP AND TESTING GUIDE

This guide is a procedure you can follow to test every feature of your door operator.

If a 3 button push-button station is wired to the operator, disconnect it and then place a normally-close contact between terminals 2 and 3 to simulate a "Stop" push-button (use a spare limit switch or any such device). Interrupting the power between these terminals will stop the operator.

Using a small wire jumper, momentarily jump (short-circuit) the following terminals:

- A. Momentarily jump terminals 3 and 4.
The door will open instantly. Allow it open completely.
- B. Momentarily jump terminals 3 and 5.
The door will close instantly. Allow it close completely.
- C. Momentarily jump terminals 7 and 8.
The door will open instantly. Allow it to open completely.
- D. Momentarily jump terminals 7 and 8.
The door will close instantly. While closing, go to step E.
- E. Momentarily jump terminals 7 and 8 again.
The door will reverse to open. Allow it to open completely.
- F. Momentarily jump terminals 7 and 8.
The door will close. While closing, go to step G.
- G. Momentarily jump terminals 3 and 6.
The door will reverse to open. Allow it to open completely.
- H. Momentarily jump terminals 7 and 8 again.
The door will close. Allow it to close completely.
- I. Momentarily jump terminals 3 and 6.
The door should remain still.

This procedure can be repeated using the radio-control terminal strip located on the outside of the control box by using terminals "24VAC" and "CONTACT" instead of terminals 7 and 8.

The following trouble-shooting guide (TABLE 3) will help you identify the source of the problem given a particular symptom.


TABLE 3 TROUBLE-SHOOTING GUIDE

SYMPTOM	PROBABLE CAUSE	SUGGESTED ACTION
Door will not respond to "open" or "close" push-button.	Motor has overworked and the overload thermal protection has tripped.	Reset the overload protection: press reset button located on the side of the unit for a single phase operator. For a three phase operator, thermal switch is inside the motor, let the motor cool and restart operator. Is the door unbalanced?
	Circuit breaker tripped (if used).	Reset circuit breaker.
	Fuse is blown.	<p>Replace fuse. If control circuit fuse keeps blowing: Disconnect all external devices. Leave power terminals connected. (Remove power to power jumpers and shorting out the appropriate terminals as indicated in the Start-Up and Testing Guide. Then reconnect the various external devices one by one until you find the one causing the short to ground.</p> <p>OR: If you have an ohm-meter, use it to check all incoming wires for continuity to ground. The meter should read infinity in all instances. If there is conduction between any control circuit wire and ground, this indicates a leak to ground and this is why the control circuit fuse blows when power is applied.</p> <p>In some cases, the trouble is intermittent: i.e. the fuse only blows at certain times. This problem is more difficult to detect, but again: disconnect all wires going to external devices, and run the operator: if the fuse does not blow, this indicates that the trouble resides outside the operator.</p>
	Transformer defective.	Replace.
	Defective "stop" push-button.	Replace.
	Loose connection in one of the push-buttons.	Verify, tighten or replace.
	Defective "open" or "close" push-button.	Replace.
	Door will not respond to "open" command, but will respond to "close" command.	Defective "open" push-button.
Defective "open" limit switch.		Replace
Loose wire on "open" push-button, "open" limit switch or coil of open contactor.		Verify, tighten or replace.
Door will not respond to "close" command, but will respond to "open" command.	Defective "close" push-button.	Replace.
	Defective "close" limit switch .	Adjust
	Loose wire on close push-button, close limit switch or coil of close contactor.	Verify, tighten or replace.
Door moves in wrong direction with a three phase motor	Incorrect phasing.	Interchange any two power leads.
Door closes by itself and operator does not shut-off at the end of closing travel.	"close" contactor is defective.	Verify and replace.
	"close" limit switch defective	Verify and replace.
Door opens by itself and operator does not shut-off at the end of opening travel.	"open" contactor is defective.	Verify and replace.
	"open" limit switch is defective.	Verify and replace.
Door coasts when stopped at any position.	Brake pad is worn out or requires adjustment.	Replace or adjust.
Sensing edge does not reverse door.	Pneumatic hose broken, electrical wiring not connected.	Contact a qualified installer.

SYMPTOM	PROBABLE CAUSE	SUGGESTED ACTION
Reversing devices will open the door when the door is closed.	The <i>advanced close</i> limit switch is defective.	Replace.
	The <i>advanced close</i> limit switch is not being engaged by travelling cam.	The <i>advanced close</i> limit switch needs to be adjusted just slightly ahead of the end of travel <i>Close</i> limit switch.
When door closes it reverses to fully open after it hits the floor.	The <i>advanced close</i> limit switch is defective.	Replace.
	The <i>advanced close</i> limit switch is not being engaged by travelling cam.	The <i>advanced close</i> limit switch needs to be adjusted just slightly ahead of the end of travel <i>Close</i> limit switch.
	A "Close" command is being given.	Check "Close" push-button or any closing device for short-circuit.
Radio-control does not function or hesitates for 10 seconds before working.	It is normal for a radio receiver to take up to 10 seconds to "warm-up" before being fully operational. Therefore, when applying power for the first time, the radio-control will take 10 seconds before becoming fully operational.	Check protocol code pins of the transmitter and receiver: they must be the same. Press on the transmitter and listen to the receiver: you should hear a faint click. The transmitter battery may be dead or your receiver may need servicing. To test for radio-control function, short out momentarily terminals 7 and 8 on the terminal strip. Operator should function normally. Have the radio-control verified: the mini-relay inside the receiver may be defective.
Motor hums, starts when spun.	Capacitor defective.	Replace
Motor fails to shut off at fully closed or opened positions.	Defective limit switch.	Operate limit switch manually while door is moving. If door does not stop, replace switch.
	Limit cams are not adjusted.	Verify and adjust.
	Limit drive chain broken.	Replace.
	Loose sprocket on limit shaft.	Tighten set screw.
	Limit shaft does not rotate.	Verify and replace accordingly.
Motor turns but door does not move.	Sprocket key is missing.	Replace.
	Drive chain is broken.	Replace.
	Clutch is slipping.	Adjust clutch tension.
Motor hums or does not run.	Door locked or jammed.	Verify manual operation of door.
	Dead phase (three phase supply).	Check power supply, fuses on each phase.
	Brake does not release.	Check wires to brake solenoid. Verify and adjust brake tension.
Limit switches do not hold their setting.	Loose drive or limit chain allows chain to jump sprocket teeth.	Adjust chain to proper tension
	Limit cam retainer not engaging slots in limit cams.	Be sure retainer is in slots of BOTH cams.
	Limit cams are binding on shaft threads which allows them to jump position on retainer.	Lubricate shaft threads. Limit cams should turn freely.
Radio-control opens and reverses the door, but when the door is fully opened, will close the door a little and bounce back to the open position again. Door cannot be closed except by the "close" push-button.	The <i>Advanced Open</i> limit switch is insufficiently advanced from the full <i>Open</i> limit switch. The contact of the radio-control receiver is maintained for 1.5 seconds when a command is issued by the radio transmitter. Therefore, when the door is fully opened, and a pulse is sent from the transmitter, the receiver maintains the contact closed for 1.5 seconds. If the door has closed and the <i>Advanced Open</i> limit switch has returned to its normal state, the reversing relay will be activated, and the door bounces back to the open position.	Adjust the <i>Advanced Open</i> limit switch by bending the switch arm away from the <i>Open</i> limit switch arm and more towards the travelling cam.

9.6 Single phase hardwired wiring diagram

DRAWING-M11MAB-W



LINE POWER	24 VAC POWER	EXTERNAL INTERLOCK	SAFETY REVERSE	OPEN/CLOSE COMMAND	PUSH-BUTTON STATION	TWO PUSH-BUTTON STATION	RADIO CONTROL

ATTENTION- USE 18AWG OR HIGHER FOR WIRING ALL EXTERNAL CONNECTIONS

NOTE: TRANSFORMER AND MOTOR RELAY ARE SAME AS THE LINE VOLTAGE.
 *2. BLUE JUMPER D-2 AND D-4 IS NOT REQUIRED FOR 230 VAC MOTORS.
 *3. TO REVERSE ROTATION FOR 120/230VAC MOTORS INTERCHANGE BLACK AND WHITE WIRES ON REVERSING CONDUCTOR.


NOTE: PLACE A JUMPER BETWEEN TERMINAL 2 AND TERMINAL 3. IF STOP BUTTON IS NOT USED.

- 1 ON SITE MODIFICATIONS**
- NOTE (C2)/(B2)
 - C2 ⇔ B2
 - 1A REMOVE THE RED WIRE WITH RAPID CONNECTOR FROM TERMINAL #5, AND TRANSFER IT TO TERMINAL #7.
 - B2 ⇔ C2
 - 1B REMOVE THE RED WIRE WITH RAPID CONNECTOR FROM TERMINAL #5, AND TRANSFER IT TO TERMINAL #7.

WARNING:

MOTORIZED DOORS CAN CAUSE SERIOUS INJURIES OR DEATH. MANARAS STRONGLY RECOMMENDS THE USE OF ENTRAPMENT PROTECTION SYSTEMS, ESPECIALLY IN THE CASES OF MOMENTARY CONTACT TO CLOSE AS IN B2 WIRING OR TIMER TO CLOSE.

- 2 CONSTANT PRESSURE OPEN
- 3 WIRING FOR INSTANT STOP (ON SAFETY EDGE OR DISTANCE)
- 4 ADDING A TIME DELAY ON REVERSE
- 5 PERFORM THE MODIFICATION EXPLAINED IN THE NOTES, 1B, 2 AND 3
- 6 ANY OTHER OPTIONS



FOR ANY OTHER OPTIONS LIKE TIMER TO CLOSE, MID-STOP WIRING, LONG DISTANCE MODULE, OR ANY OTHER SPECIAL LOGIC SEQUENCE PLEASE CONSULT MANARAS AT 1-800-361-2800/1-866-226-0260.


WIRING DIAGRAM FOR M1/MS/NTB/120/230 VAC, 1 PHASE MOTORS

M11MAB-W

PROJECT	DATE
CLIENT	14 OCT 2004
ENGINEER	
DISTRIBUTOR	
M.F.D. BY	MANARAS AUTO DOORS INC.



DRAWING-M31MABJ1-W



NOTE:-
 #1- TRANSFORMER IS SAME AS THE LINE VOLTAGE
 #2- TO REVERSE MOTOR ROTATION INTERCHANGE ANY TWO WIRES ON REVERSING CONTACTOR

LINE POWER	24 VAC POWER	EXTERNAL INTERLOCK	SAFETY REVERSE	OPEN/CLOSE COMMAND	PUSH-BUTTON STATION	TWO PUSH-BUTTON STATION	RADIO CONTROL
L1 L2 L3 POWER SUPPLY 3Ø/460/575 VAC	1 9 24 VAC POWER AVAILABLE FROM MM.	1 2 FACTORY INSTALLED JUMPER REMOVE IF EXT. INTERLOCK IS USED	3 6 CONTACT FOR SAFETY EMERGENCY DEVICE	7 8 CONTACT FOR OPEN/CLOSE DEVICE	2 3 4 5 STOP OPEN CLOSE	2 3 4 5 STOP OPEN CLOSE	7 8 9 POWER PURPLE CONTACT BLUE GROUND BROWN

ATTENTION- USE 18AVG OR HIGHER FOR WIRING ALL EXTERNAL CONNECTIONS

NOTE:- PLACE A JUMPER BETWEEN TERMINAL 2 AND TERMINAL 3 IF STOP BUTTON IS NOT USED.

WIRING DIAGRAM FOR M/MSI/MH/NTHS 2Ø8/460/575 VAC. 3 PHASE MOTORS			
TITLE	DES	REV	DATE
M31MABJ1-W	BS	1	14. OCT. 2004
PROJECT	CLIENT	ENGINEER	DISTRIBUTION
M.F.D. BY	MANARAS AUTO DOORS INC.		

1 ON SITE MODIFICATIONS

- 1 REMOVE THE RED WIRE WITH RAPID TRANSFER IT TO TERMINAL #7, AND TRANSFER IT TO TERMINAL #5, AND B2 ↔ C2
- 1B REMOVE THE RED WIRE WITH RAPID TRANSFER IT TO TERMINAL #5, AND TRANSFER IT TO TERMINAL #5.
- 1C REMOVE THE RED WIRE WITH RAPID TRANSFER IT TO TERMINAL #5, AND TRANSFER IT TO TERMINAL #5.


WARNING:

MOTORIZED DOORS CAN CAUSE SERIOUS INJURIES OR DEATH. MANARAS STRONGLY RECOMMENDS THE USE OF EQUIPMENT RECORDS TO IDENTIFY THE EQUIPMENT IN THE CASES OF MOMENTARY CONTACT TO DO AS IN B2 WIRING OR TIMER TO CLOSE.

- 2 CONSTANT PRESSURE OPEN AND PLACE IT ON TERMINAL # 4
- 3 WIRING FOR INSTANT STOP (ON SAFETY EDGE OR DEVICE) 1. REMOVE THE YELLOW WIRE FROM ADV. OPEN LIMIT SWITCH, AND CAP IT. 2. REMOVE THE BLUE WIRE FROM PIN # 4 OR REVERSING RELAY(RR) AND CAP IT.

- 4 ADDING A TIME DELAY ON REVERSE ADV. OPEN L.S. 1. REMOVE THE YELLOW WIRE FROM ADV. OPEN LIMIT SWITCH, CONDUCT THIS WIRE TO ONE END OF TIME-DELAY. 2. REMOVE THE BLUE WIRE FROM PIN # 4 OR REVERSING RELAY(RR) AND CAP IT.

- 5 CONSTANT PRESSURE OPEN & CLOSE- D1 PERFORM THE MODIFICATION EXPLAINED IN THE NOTES, 1B 2 AND 3
- 6 ANY OTHER OPTIONS FOR ANY OTHER OPTIONS LIKE, TIMER TO CLOSE, FOR ANY OTHER SPECIFIC LAST IN SEQUENCE OR ANY OTHER SPECIFIC LAST IN SEQUENCE PLEASE CONSULT MANARAS AT 1-800-381-2880/ 1-866-77-6732(USA)



WARRANTY

Manaras warrants its operators to be free from defects in material and workmanship under normal and proper use for a period of two years from date of invoice. Mechanical, electrical and electronic accessories are warranted for one year from date of invoice. Wearing parts such as clutch pads, v-belts, and brake bands are excluded from warranty.

Manaras' only obligation shall be to repair or replace defective equipment which does not conform to the warranty. Manaras shall not be liable for any injury, loss or damage, direct or consequential, arising out of the inability to use the equipment. Before using, Buyer and/or the ultimate User shall determine the suitability of the product for its intended use, and User assumes all risks and liability in connection therewith. The foregoing may not be changed except by an Agreement signed by an authorized representative of Manaras.

The articles that are replaced pursuant to the terms of this warranty shall be retained by Manaras, and the User is responsible for any freight costs relating to repair or replacement.

The foregoing warranty is exclusive and in lieu of all other warranties of quality, whether written, oral or implied (including any other warranty of merchantability or fitness for purpose).

The following are exclusions from warranty:

- If usage, product modification, adaptation or installation are not in accordance with our installation and operating instructions.
- If the product has been opened, dismantled or returned with clear evidence of abuse or other damage.
- If our written specifications are not properly applied by the Buyer when selecting the equipment.
- If our written instructions for installation and wiring of the electrical connections have not been followed.
- If our equipment has been used to perform functions other than the functions it was designed to handle.
- If Manaras equipment is used with electrical accessories (switches, relays, etc.) that have not been previously approved in writing by the Manaras Engineering Department.
- If electrical accessories and other components have been used in disregard of the basic wiring diagram for which they were designed.

All costs related to installation and reinstallation of the Manaras equipment covered by this warranty are not the responsibility of Manaras. Manaras will not be responsible for any consequential damages during the following installation procedures. If the Buyer resells any Manaras products to another Buyer or End-user, it shall include all of the terms and provisions of this warranty in such resale. Manaras' responsibility to any such Third Party shall be no greater than Manaras' responsibility under the warranty to the original Buyer.

Returns

No returns will be accepted without prior written authorization by Manaras. All returns must be accompanied by a Return Authorization Number issued by Manaras, and all unauthorized returns will be refused. The return shipment is to be freight prepaid by the Buyer, and under no circumstances shall the Buyer deduct the value of the returned merchandise from any remittance due. A restocking fee of 15% of Manaras sale price will be charged.



Commercial Door OPERAtor



Manaras-Opera is extending their well-known OPERA brand name across its entire line of Commercial Door OPERATORS. Over the years, the OPERA brand name has become synonymous with innovation and reliability. The high quality products you have come to expect from us will now be backed by the OPERA brand name.

**When you think
Commercial Door OPERATORS,
just think OPERA.**

Call us for more information
1-800-361-2260

www.manaras.com