Installation & Instruction Manual



MLT

Commercial & Industrial Medium Duty Trolley Operator
(For standard lift sectional doors)

Electrical Control (BOARD 100E)

READ AND FOLLOW ALL INSTRUCTIONS. SAVE THESE INSTRUCTIONS. GIVE TO END-USER.
Serial # _____
Model # _____
Wiring Diagram # _____
Project #/Name _____
Door #/Name _____

Manaras Opera

For technical support, please call **1-800-361-2260** or visit **www.manaras.com** for more information

Table of Contents

Installation Instructions **3**
1 General Specifications and Dimensions 4
2 Door & Operator Hardware 5
2.1 Delivery of Operator 5
2.2 Hardware Supplied 5
3 Operator Installation 6
3.1 Assembly Instructions 6
3.2 Installation 8
4 Disconnect Mechanism 10
5 Limit Switches & Limit Cams: Adjustment & Functionality 11
5.1 Limit Switch Adjustments: Open and Close Cam Settings 11
5.2 Limit Switch Functionality 11
5.3 Limit Switch Adjustment 12
6 Electrical Wiring 13
6.1 Low Voltage (Controls) and High Voltage (Power) Connections 14
6.2 Main Power Supply Connection 14
6.3 Wall-Button Connection 15
6.4 Optional Accessory Connections 16
7 Operator Start-up 20
8 Clutch Adjustment 21
9 Electronic Control Board (ECB) – BOARD 100E 22
9.1 General Layout 22
9.2 On-Board LED Monitoring Status 23
9.3 Electronic Control Board (ECB) Programming 25
User Instructions **28**
1 Quick Fix Instructions 29
Maintenance Instructions **30**
1 Preventative Maintenance Schedule 30
1.1 Mechanical Inspection 30
1.2 Electrical Inspection 31
2 Troubleshooting Guide 32
3 Electrical Drawings 34
3.1 1 Phase Operator with BOARD 100E 34
3.2 External Wiring with BOARD 100E 35
4 Mechanical Exploded Views and Replacement Components 36
4.1 MLT 36
4.2 MLT Control Box with BOARD 100E 37
Notes **38**
Warranty **39**

Installation Instructions

IMPORTANT INSTALLATION INSTRUCTIONS

⚠ WARNING

TO REDUCE THE RISK OF SEVERE INJURY OR DEATH TO PERSONS:

1. READ AND FOLLOW ALL INSTALLATION INSTRUCTIONS.
2. Install only on a properly operating and balanced door. A door that is operating improperly could cause severe injury. Have qualified service personnel make repairs to cables, spring assemblies and other hardware before installing the operator.
3. Remove all pull ropes and remove, or make inoperative, all locks (unless mechanically and/or electrically interlocked to the power unit) that are connected to the door before installing the operator.
4. Installation of this door operator must be done by a qualified installer.
5. Verify that the operator is correct for type, size of door and frequency of use per the operator specifications.
6. Install the door operator at least 8 feet (2,4 m) or more above the floor if the operator has exposed moving parts.
7. Do not connect the door operator to the source of power until instructed to do so.
8. Locate the control station: (a) within sight of the door, (b) at a minimum height of 5 feet (1,5 m) so small children cannot reach it, and (c) away from all moving parts of the door.
9. Install the Entrapment Warning Placard next to the control station in a prominent location.
10. For products having a manual release, instruct the end user on the operation of the manual release.
11. If you have any questions about the safety of the door operating system, do not install the operator, contact Manaras-Opera at 1-800-361-2260.

1 General Specifications and Dimensions

SUPPLY VOLTAGE	115 VAC single-phase
CONTROL VOLTAGE	24 VAC class 2 transformer, 1 amp fuse type ACG
MOTOR	Intermittent duty 1/2 horsepower
DOOR SPEED	11”/second
NET WEIGHT (Operator only)	60 Lbs (27 Kg)
STANDARD WIRING TYPE	C2 (momentary contact to open/stop and constant-pressure-to-close)
APPLICATION	Medium duty for standard lift sectional doors
DUTY	14 cycles/hour or 50 cycles/day maximum



Figure 1 - MLT Dimensions

Table 1 - Operator Selection Guide

Maximum Area in Square Feet (general guideline)

Sectional Doors					
HP	Steel 18 ga ins.	Steel 18 ga 20 ga ins.	Wood Steel 20 ga, 22 & 24 ga ins.	Alu. Steel 22 & 24 ga	Fiber Glass
½	120	160	250	275	290

2 Door & Operator Hardware

2.1 Delivery of Operator

Upon delivery of your OPERA™ trolley operator, inspect the unit immediately for any shipping damages. Verify that you have received all the hardware parts pertaining to your operator model, as listed in Table 2 and shown in Figure 2. If ordered, other items such as radio controls or other types of optional equipment may be present. If any item is missing or if there is evidence of damage, call the transport company or your direct supplier.

2.2 Hardware Supplied

Table 2 - Standard Hardware Parts Supplied

No	Qty	Description	
1	1	3-Push-button station (open/close/stop)	
2	1	Door lifting arm assembly	
3	2	Pre-drilled galvanized track (1)	Txxx
4	1	#410 (48)/#41 Drive chain (1)	
5	1	Front end u-bracket	
6	1	#410 (48)/#41 Front idler assembly	
7	2	Spacer	
8	1	Carriage	
9	6	Hex bolt 3/8-16 x 1-1/4”	T2-HBAG
10	1	Hex bolt 3/8-16 x 2-1/4”	
11	1	Take-up bolt 3/8-16 x 2-1/2”	
12	1	Connecting chain link	
13	8	Hex nut 3/8-16	
14	7	Helical spring lock washer 3/8	
15	1	Lock nut 3/8-16	
16	1	Entrapment Warning Placard	

(1) Length according to door height

Note: Depending on door height, the quantity of track hardw are may vary.



Figure 2 - Standard Trolley Hardware

Figure 3 - Entrapment Warning Placard

NOTE: Install the **Entrapment Warning Placard** (shown in Figure 3), next to the control station, visible in the area of the door.

3 Operator Installation

3.1 Assembly Instructions

⚠ CAUTION

To prevent access to the pinch point, this operator must be installed a minimum of 8 feet (2,4 m) above the floor.

NOTICE

• Install the operator only when all openings of a horizontal slide door are guarded or screened from bottom of the door to a minimum of 4 ft (1,22 m) above the ground to prevent a 2-¼ in (57,2 mm) diameter sphere from passing through the openings anywhere in the door.

1 Attach tracks to operator



2 Assemble carriage



3 Slide carriage on track



4 Install spacers and front idler



5 Install chain

A) Attach chain to front of carriage.



B) Wrap chain around front idler.





C) Wrap chain around operator sprocket.



D) Attach chain to back of carriage.





E) Adjust the tension on the chain.

3.2 Installation

Trolley operators are designed to be mounted directly over the center of the door. The operator tracks should clear the door by approximately 2.5”. Off center mounting may be required, for example, because of potential interfering structures. It is possible to install the operator slightly off the center on torsion spring doors. Extension springs require center mounting.

1 Establish the center of the door



2 Establish the highest point of door travel



3 Position the U-shaped wall bracket



Secure w all bracket to header using the appropriate anchors for your type of w all.

4 Attach tracks to U-shaped wall bracket



Allow the motor to rest on the floor and raise the front end of the rails and secure w ith the bolts and nuts (do not tighten).



5 Position and hang the operator

Hoist the rear of the operator to a horizontal position. Temporarily secure with rope or chain. Tighten wall bracket bolts and nuts.



Secure the operator using hanging brackets and appropriate fasteners. It is highly recommended to secure the tracks. The number and type of supports used is left up to the discretion of the installer based on the environmental constraints.

6 Attach door arm

Attach door arm to carriage.



Attach door arm to door using appropriate fasteners. Mount door bracket to the center of the door.



Door arm should ideally hang vertically when the door is closed.



4 Disconnect Mechanism

⚠ WARNING

To reduce risk of SEVERE INJURY or DEATH to persons:

- Do not stand directly under door arm when pulling the disconnect chain.
- Do not attempt to disengage the door while the operator is running.
- Do not attempt to manually force open or close a malfunctioning door.
- The door should ideally be closed when activating the disconnect mechanism.

The operator is equipped with a trolley disconnect mechanism to operate the door manually if necessary.

To manually operate the door:

1. Pull disconnect chain downwards, refer to Figure 4.
2. Disconnect trolley arm from carriage, refer to Figure 4.
3. Operate the door manually (by hand).

To return to electrical operation mode:

1. Pull on disconnect chain while reinserting the trolley arm onto the carriage.



Figure 4 - Disconnect Trolley Arm From Carriage

5 Limit Switches & Limit Cams: Adjustment & Functionality

⚠ WARNING

To reduce risk of SEVERE INJURY or DEATH to persons:
• Do not attempt to make limit switch adjustments unless power has been electrically disconnected.

5.1 Limit Switch Adjustments: Open and Close Cam Settings

To adjust the limit cams, see Figure 5.

1. Push the cam's retaining bracket arm.
2. Turn the cams for limit adjustment: turning cams toward the center of the limit shaft increases door travel or turning the cams toward the limit switch decreases door travel.



Figure 5 - Limit Cam Adjustment

5.2 Limit Switch Functionality

Open Limit Switch and Advanced Open Limit Switch

When activated, the Open Limit Switch will stop the operator while the door is travelling in the upward direction. Should be adjusted accordingly to stop door in fully open position. The microprocessor has a built-in program that replaces the Advanced Open Limit Switch.

Close Limit Switch and Advanced Close Limit Switch

Close Limits are not present on operators with an ECB. In it's place, the microprocessor has a built-in patented Advanced Close Time feature. While the door is travelling downwards and once the Advanced Close Limit Switch is activated, the door will stop after **200 milliseconds**. The distance travelled varies according to the speed of the door. The value is fixed and cannot be re-programmed or adjusted.

5.3 Limit Switch Adjustment

Table 3 - Limit Switch Adjustment Procedures

Limit Switch	Adjustment Procedures
Open Limit	1. Move the open cam close to the open limit switch and proceed as per described in section Operator Start-up, Table 4, p.20. 2. Release cam-retaining bracket and make sure that the bracket **engages** in the slots of both cams.
Advanced Close Limit	1. Pull the disconnect chain for manual operation. **2. Manually open the door approx. 6" above the ground.** 3. Pull the cam-retaining bracket from the Close side, see Figure 5, and rotate Close cam manually until it activates the Close limit switch sufficiently so that a "click" can be heard. 4. Release cam-retaining bracket and make sure that the bracket **engages** in the slots of both cams.
Limit Switch Fine Adjustment	1. Limit switch fine adjustment SHOULD be done after the main power supply is connected to the operator. Refer to section Operator Start-up, Table 4, p.20. Note: One (1) notch on cam is equal (=) to about ½" of the door travel.

6 Electrical Wiring

⚠ WARNING

To reduce risk of SEVERE INJURY or DEATH to persons:

- All electrical wiring should be done by a qualified professional and in accordance to local electrical codes.
- Always shut OFF the main power before performing any electrical intervention.
- Use proper wire gauge for incoming power line and for accessory connections.
- Install operator main circuit breaker next to operator for easy access for power shut-off.
- Use separate knockouts on operator control box for accessories and main power cables.
- Always separate low and high voltage wires.
- Operator should be properly grounded to the building ground and to the main power supply ground lug.
- Always use suitable and appropriate rating circuit breakers for operator protection.
- Compare available power supply voltage to voltage on operator name plate prior to electrical connection. Failure to connect appropriate power supply voltage may cause serious damage to the operator.

NOTICE

- THE OPERATOR MUST BE ADEQUATELY PROTECTED AGAINST OVERCURRENT AND SHORT-CIRCUIT.
- PLEASE REFER TO LOCAL ELECTRICAL CODE.
- PLEASE REFER TO NATIONAL ELECTRIC CODE (NFPA 70) ARTICLE 430 SECTION IV (430,51 / 430,52 / 430,53).
- PLEASE REFER TO CANADIAN ELECTRIC CODE (CSA 22,1) SECTIONS 28-200 / 28-206.



Guideline to determine the branch-circuit rating of the protective device [A]:

Time Delay Fuse: 1,75 x **FLA**
Non-Time Delay Fuse: 3,0 x **FLA**
A fuse that does not exceed the next higher standard ampere rating shall be permitted.

Example: If **FLA = 5,0A**

- Time Delay Fuse: 1,75 x **5,0A** = 8,75A → Standard fuse to use: 10A
- Non-Time Delay Fuse: 3,0 x **5,0A** = 15,0A → Standard fuse to use: 15A

NOTICE

- The installer MUST test for proper connection and functionality of the operator and its accessories before leaving the job site.
- The installer should also perform a demonstration for the end-user.

6.1 Low Voltage (Controls) and High Voltage (Power) Connections

1. Route the power line wires either from the right or from the left of the control box, as shown in Figure 6.
2. Route all low voltage control wires, as shown in Figure 6. KEEP LOW VOLTAGE WIRES SEPARATE FROM LINE VOLTAGE WIRES.
3. USE COPPER CONDUCTORS ONLY.



Figure 6 - Low Voltage (Controls) and High Voltage (Power) Connections

6.2 Main Power Supply Connection

Single-Phase (115V)



Correct motor rotation: Switch the BLUE and RED wires on the capacitor.

6.3 Wall-Button Connection

⚠ WARNING

- Wall controls must be mounted in clear view of the door, far enough from the door, or positioned such that the user is prevented from coming in contact with the door while operating the controls and at least 5 feet (1,5 m) above the standing surface.
- Keep low voltage wires separate from line voltage wires.
- Use copper conductors only.

Push-Button Station (PBS) Connection



Figure 7 - STATION 020 / 084
3-PBS Open / Close / Stop



Figure 8 - STATION 041 / 049 / 056 / 076 / 078
3-PBS Open / Close / Stop



Figure 9 - STATION 079
3-PBS Open / Close / Stop with Key Lock-out



Figure 10 - STATION 080
3-PBS Open / Close / Stop with Key Lock-out and Light



Figure 11 - STATION 001 / 081
1-PBS Open



Figure 12 - STATION 010 / 082
2-PBS Open / Close

6.4 Optional Accessory Connections

NOTICE

- Keep low voltage wires separate from line voltage wires.
- Use copper conductors only.

6.4.1 Electric Photo Cells / Photo Eyes (Non-Monitored)

Through Beam Type



Figure 13 - PHOTO 008



Figure 14 - PHOTO 015 / 016 / 045 / 050 / 051 / 059

Reflective Type



Figure 15 - PHOTO 018



Figure 16 - PHOTO 038



Figure 17 - PHOTO 060

6.4.2 Reversing Edge Device (Non-Monitored)

NOTICE

• If the door is controlled by any device other than a constant pressure push-button station on close, including a timer-to-close, a reversing edge must be connected.

Installation

Pneumatic Sensing Edge

1. Place the air switch in position, refer to Figure 18.
2. Place the air hose in position.
3. Use a coil cord or take-up reel to connect the air switch to the operator terminals. Install electric wires according to Figure 19 or Figure 20.
4. Connect one end of the air hose to the air switch.
5. Place the air plug in the other end of the air hose.

Electric Sensing Edge

1. Place the junction box in position, refer to Figure 18.
2. Place the sensing edge in position.
3. Use a coil cord or take-up reel to connect the sensing edge wires to the operator terminals. Install electric wires according to Figure 21.
4. Connect the sensing edge to the junction box.
5. N/A



Figure 18 - Reversing Edge



Figure 19 - AIRSWITCH 001 / 007



Figure 20 - AIRSWITCH 009



Figure 21 - Electric Reversing Edge

6.4.3 Pull Cord & Key Switch



Figure 22 - PULLCORD 001 / 003 / 004 / 007

2-Position Key Switch

Recommendation: Put Control Board on C2 or E2 Mode (constant-pressure-to-close)



Figure 23 - KEYSWITCH 010 / 015

2-Position Key Switch & Stop Button



Figure 24 - KEYSWITCH 019

6.4.4 External Single-Button Radio Control Receiver



Figure 25 - RADIO 014 or RADIO 015



Figure 26 - Other Radio Receivers with 4 or 5-wires

6.4.5 Vehicle Loop Detector



Figure 27 - Vehicle Loop Detector

6.4.6 Other Accessories

Additional accessories are available, such as:

- Plug-In Radio Receiver
- External Mid-Stop Switch

Please contact your dealer or our inside sales department at **1-800-361-2260** for further information.

7 Operator Start-up

⚠ WARNING

To reduce risk of SEVERE INJURY or DEATH to persons:

- Personnel should keep away from a door in motion and keep the moving door in sight until it is completely closed or opened. NO ONE SHOULD CROSS THE PATH OF A MOVING DOOR.
- Never go under a stopped, partially opened door.

1. Turn power ON.
2. Use on-board, wall-button station (Open/Close/Stop), external entrapment device or jumper wires for testing, see Table 4.

Table 4 - Start-up and Testing Guide

Test	Door Position	Action	Door Response	LED Status
Open	Door at 6" from the closed position	1. Press "OPEN". 2. Check if door is stopped by Open limit switch. 3. If required, re-adjust Open limit, as shown in Figure 5, p.11.	Door should open instantly.	D4 "OPNLMT" LED is ON
Close	Door at fully open position	1. Press "CLOSE". 2. Check if door is stopped by Close limit switch. 3. If required, re-adjust Close limit, as shown in Figure 5, p.11.	**- C2 mode:** *(selector switch on C2=0).* Door should close as long as the close button is activated. **- B2 mode**: *(selector switch on B2=1).* Door should close instantly.	D5 "CLSLMT" LED is ON
Sense Edge	A) Door at fully closed position	Activate external entrapment device OR Momentarily touch #3 & #5 on the main terminal with a jumper wire.	Door should stay at closed position.	D6 "SENS" LED is ON as long as the contact is maintained
	B) Door is closing (movement)		Door should stop and then reverse to fully opened position.	
Open & Close (single-button radio)	A) Door at fully opened position	Activate the single-button transmitter OR Momentarily touch #3 & #4 on the main terminal with a jumper wire.	Door should close.	D7 & D8 "OPEN & CLOSE" LEDs are ON as long as the contact is maintained *(+/- 2 sec)*
	B) Door at fully closed position		Door should open.	
	C) Door is closing (movement)		Door should reverse to fully opened position.	

8 Clutch Adjustment

NOTICE
• The friction clutch is NOT intended to protect people. It is designed to protect the operator and door system against potential damage. • The friction clutch is factory adjusted during final testing. Proper adjustments should be done on site according to the door characteristics and application.

Best Practices Encouraged by Manaras-Opera

Manaras-Opera recommends the installation of a hard stop at the end of the tracks (ex. bolt, deformation of tracks, bumper spring, pusher spring, etc). With such installation, the door is prevented from running out of the tracks. The clutch (torque limiter) will prevent any damage to occur to the door system.

This operator is supplied with a **Door Lock Sensor feature**. The door lock sensor feature prevents the door from getting damaged when the door lock hasn't been removed prior to electronic operation. It eliminates the need of expensive external interlock wiring.

This feature can only be used on operators equipped with a friction clutch. When the lock stops the door, the clutch slips and in less than 1 second, the door will reverse a fraction of a second to release the tension on the lock.



Figure 28 - Clutch Adjustment

To adjust the clutch:

1. Unlock the jam nuts with two (2) 7/8” keys, refer to Figure 28.
2. Rotate the nut counter-clockwise to release the tension.
3. Gradually rotate the nut clockwise until there is just enough tension to permit smooth operation (while still allowing the clutch to slip if the door is obstructed).
4. Lock the jam nuts.

9 Electronic Control Board (ECB) – BOARD 100E

9.1 General Layout



Figure 29 - Electronic Control Board – BOARD 100E

9.2 On-Board LED Monitoring Status

The electronic control board's LEDs help with wiring and troubleshooting diagnostics. Every LED indicates the status of the door. BOARD 100E has a non-volatile memory and the LEDs return to their initial state after a power interruption. Refer to Figure 29, p.22 as reference.

Table 5 - LED Monitoring Status

LED	Color	LED Status	Functions
D1	**GREEN**	**ON**	Indicates presence of 24VDC.
D2/D3	Refer to Table 6, p.24 as reference.		
D4	**RED**	**ON**	When open limit switch is activated.
D5	**RED**	**ON**	When close limit switch is activated.
D6	**RED**	**ON**	When reversing or sensing edge is activated.
D7	**RED**	**ON**	When close command is activated.
D8	**RED**	**ON**	When open command is activated.
D9	**YELLOW**	**ON**	Indicates that the stop button is connected and hoist or disconnect switch is not engaged.
D10	**RED**	**ON**	When inductive loop is activated.

9.2.1 D2 / D3 LED Monitoring Status Combination Scenarios

Table 6 - D2/D3 LED Monitoring Status - Combination Scenarios

Scenario	D2 LED GREEN	D3 LED RED	Functions
1	**OFF**	**OFF**	Indicates a failure of the 5VDC.
2	**OFF**	**Flash**	When door is closing.
3	**ON**	**OFF**	When operator is on standby.
4	**ON**	**Flash**	Indicates wrong handling feature activation *(if open limit switch is not released within 3.6 sec while door starts to close from fully open position).*
5	**Flash**	**OFF**	When door is opening.
6	**Flash**	**Flash**	When timer to close is counting before closing the door.
7	**Flash**	**Flash**	When door is opening during programming of the run timer feature. Refer to section 9.3.2, p.26 as reference.

9.3 Electronic Control Board (ECB) Programming

⚠ WARNING

To reduce risk of SEVERE INJURY or DEATH to persons:

- Manaras-Opera strongly recommends the use of external entrapment protection devices, especially in the case of momentary contact to close (B2 wiring or Timer to Close).

9.3.1 Run Mode Settings

NOTICE

- Always return the door to **fully closed position** before performing any program settings.

C2 Mode  Selector switch position on **0**	**SET SELECT SWITCH ON *C2 = 0*** **Function:** Momentary contact to open and stop, constant-pressure-to-close with 3-button station. Activation of safety devices will reverse the door while closing. Auxiliary devices function as an Open control and will reverse the door while closing.	**E2 Mode**  Selector switch position on **3**	**SET SELECT SWITCH ON *E2 = 3*** **Function:** Momentary contact to open and constant pressure to Close. Release of Close button or activation of safety devices will reverse the door to fully open position.
B2 Mode  Selector switch position on **1**	**SET SELECT SWITCH ON *B2 = 1*** **Function:** Momentary contact to Open, Close and Stop with 3-button station. Activation of safety devices will reverse the door during closing. Auxiliary devices function as Open-Close control and will reverse the door while closing.	**T Mode**  Selector switch position on **4**	**SET SELECT SWITCH ON *T = 4*** **Function:** Under Mode T=4, if safety devices are activated while door is closing, door will reverse and will not close by Timer to Close (TTC). TTC will also be disabled if the chain hoist is engaged or if the stop is activated before elapsed time. TTC will resume its normal operation only after the door is fully closed.
D1 Mode  Selector switch position on **2**	**SET SELECT SWITCH ON *D1 = 2*** **Function:** Constant-pressure-to-open and constant-pressure-to-close. Activation of safety devices will stop the door while closing.	**TS Mode**  Selector switch position on **5**	**SET SELECT SWITCH ON *TS = 5*** **Function:** Under Mode TS=5, if safety devices are activated while door is closing, door will reverse and will close by Timer to Close (TTC). TTC will also be refreshed if the chain hoist is engaged, if the stop is activated before elapsed time or in case of a power outage.

T (4) & TS (5) Mode: Only applicable with Timer to Close, refer to Features Programming section, p. 26.

9.3.2 Features Programming

NOTICE

• Always return the door to **fully closed position** before performing any program settings.

Maximum Run Timer

Maximum run timer is set to 90 seconds by default. When programmed, this feature calculates the total time required for the door to travel from the fully closed to the fully opened position and adds 10 seconds to this time. Therefore, if the door is obstructed while travelling up or down, this feature will stop the operator after the maximum run timer time has elapsed.

Run Timer Programming	Select Switch	Set Run Timer to Default
1. Verify if close limit switch is activated and if close LED is ON. 2. Set select switch on ***D = Run Tm***. 3. Press "Open" button and let the door reach the fully opened position. **Result: 10 sec** is added to the total travel time. 4. Set select switch on run mode ***(0, 1, 2, 3, 4 or 5)***.		1. Verify if close limit switch is activated and if close LED is ON. 2. Set select switch on ***D = Run Tm***. 3. Press "Stop" button. **Result:** The max. run timer is set to the default value of **90 sec**. 4. Set select switch on run mode ***(0, 1, 2, 3, 4 or 5)***.

Timer to Close (TTC)

Timer to Close (T = 4 or TS = 5 Mode), will close the door from the fully opened position after a factory preset time (5 sec.). Timer to Close can be programmed in increments of 1 sec. or 15 sec.

TTC Programming	Select Switch	TTC Deactivation
1. Verify if close limit switch is activated and if close LED is ON. 2. Set select switch on ***B = Tm Cls***. 3. Press the "Stop" button to return the time to **0 sec.** or to reprogram. 4. Press "Open" button to add 15 sec. increments, or press "Close" button to add 1 sec. increments. Max. 4 min. 5. Set select switch on ***T = 4 or TS = 5***. Refer to Run Mode Settings section, p. 25 for mode descriptions.		1. If the TTC is not required, set select switch on run mode **(*0, 1, 2, or 3)***.

Timer to Close User Suspension Feature

This feature allows the Timer to Close to be enabled/disabled from the floor by using a wall push-button station. This feature allows the user to keep the door opened for ONE CYCLE only.

TTC Deactivation	TTC Activation
While the door is in the closed position, by pressing the "Stop" button 3 times and the "Close" button 3 times consecutively on the push-button station, the TTC is deactivated (*TTC is suspended*).	The TTC is re-activated (*TTC returns to normal function*) when the door is closed.

Single-Button Control (SBC)

With this feature, it is possible to use a single-channel transmitter for a Commercial Application, as well as a Single-Button Control (SBC). The SBC provides the user with the possibility to open, stop or close the door by using a single-button radio transmitter (or a single push-button station).

SBC Activation	Select Switch	SBC Deactivation
1. Verify if close limit switch is activated and if the close LED is ON. 2. Set select switch on ***9 = SBC***. 3. Press ”Open” button. 4. Set select switch on run mode ***(1, 4, or 5)***.		1. Verify if the close limit switch is activated and if the close LED is ON. 2. Set select switch on ***9 = SBC***. 3. Press the “Stop” button. 4. Set select switch on run mode ***(0, 1, 2, 3, 4 or 5).***

Please contact your dealer or our inside sales department at **1-800-361-2260** for further information.

User Instructions

IMPORTANT SAFETY INSTRUCTIONS

⚠ WARNING

TO REDUCE THE RISK OF SEVERE INJURY OR DEATH TO PERSONS:

1. READ AND FOLLOW ALL INSTRUCTIONS.
2. Never let children operate or play with door controls. Keep the remote control (where provided) away from children.
3. Personnel should keep away from a door in motion and keep the moving door in sight until it is completely closed or opened. NO ONE SHOULD CROSS THE PATH OF A MOVING DOOR.
4. Test the door's safety features at least once a month. After adjusting either the force or the limit of travel, retest the door operator's safety features. Failure to adjust the operator properly may cause severe injury or death.
5. For products having a manual release, if possible, use the manual release only when the door is closed. Use caution when using this release with the door open. Weak or broken springs may cause the door to fall rapidly, causing severe injury or death.
6. KEEP DOORS PROPERLY OPERATING AND BALANCED. See Door Manufacturer's Owner Manual. An improperly operating or balanced door could cause severe injury or death. Have trained door systems technician make repairs to cables, spring assemblies and other hardware.
7. SAVE THESE INSTRUCTIONS.

IMPORTANT
For more information or for immediate assistance, please contact your local dealer.

NOTICE

- The installer should perform a demonstration of the operator and it's accessories (ex: push-button station, radio control), external entrapment protection device and manual release for the end-user.

For instructions regarding the Manual Release, refer to the Installation Instructions found in section 4, p.10.

1 Quick Fix Instructions

Table 7 - Basic Troubleshooting Guide ~ from floor level

Symptom	Possible Cause	Fix Problem
Door doesn't respond to any command	◆ "Stop" button is stuck. (LED D9 is OFF)	➔ Press and release the "Stop" button on the wall station several times.
	◆ No power supply. (LED D2 is OFF)	➔ Verify the incoming power line from the main breaker, making sure it has not tripped or blown a fuse.
Door doesn't not respond to "Close" or radio commands	◆ Photo cells are not properly aligned or are obstructed.	➔ Clear the obstruction or re-align photo cells.
	◆ Loop is obstructed (presence of metal). (LED D10 is ON)	➔ Clear the obstruction.
When pressing "Open" button, door opens ~1-2 ft, then stops and reverses	◆ Mechanical door lock is engaged.	➔ Release the door lock.
	◆ Verify if the rubber seal at the bottom of the door is frozen to the ground (winter time).	➔ Clear ice and free the rubber seal at the bottom of the door.
Door doesn't respond to any radio command	◆ No power supply. (transmitter light is OFF)	➔ Replace transmitter's battery.
	◆ Poor radio control range.	➔ Bring the radio transmitter closer to the operator.
	◆ Photo cells are not properly aligned or are obstructed.	➔ Clear the obstruction or re-align photo cells.
Timer to Close doesn't close the door	◆ Timer to Close has been suspended accidentally for ONE cycle.	➔ Timer to Close will return to normal after the door has been fully closed. Refer to p.26 for further details.
Timer to Close closes the door after being suspended	◆ Timer to Close has been reactivated accidentally.	➔ To suspend the Timer to Close, close the door completely. Then press the "Stop" button 3 times and then press the "Close" button 3 times. Refer to p.26 for further details.

Maintenance Instructions

IMPORTANT SAFETY INSTRUCTIONS

⚠ WARNING

TO REDUCE THE RISK OF SEVERE INJURY OR DEATH TO PERSONS:

- Inspections, service and repairs should be performed anytime a malfunction is observed or suspected.
- Only qualified persons should perform maintenance on a door operator and all safety precautions should be taken into consideration.
- When servicing, always disconnect operator from main power supply.
- KEEP DOORS PROPERLY OPERATED AND BALANCED.
- See Door Manufacturer's Owner Manual. An improperly operated or balanced door can cause severe injury or death. Have qualified door system technicians perform repairs to cables, spring assemblies and other hardware.

1 Preventative Maintenance Schedule

1.1 Mechanical Inspection

The door area should always be kept clear of dirt, rocks or any other substances in order to insure proper operation. Maintenance of the door operator should be performed according to the schedule in Table 8 and Table 9.

Table 8 - Mechanical Inspection Schedule (Part 1)

Time Frame	Inspection
Every Month	• Test the door's safety features. • Verify the brake function (if applicable). • After adjusting either the clutch or the limit's travel, retest the operator's safety features. • Verify gear reducer's oil level (if applicable).
Every 3 Months	• Verify and adjust the clutch if necessary.
Every 6 Months	• Lubricate all moving parts. Bushings are oil impregnated and are lubricated for life. • Verify that all mechanical parts function properly. • Inspect the V-belt and adjust or replace if necessary. • Manually operate the door. If the door does not open or close freely, correct the cause of the malfunction.

Table 9 - Mechanical Inspection Schedule (Part 2)

Time Frame	Inspection
Once a Year	• Run the operator a few cycles: ◦ Make sure that the door rollers are rolling smoothly on the track. ◦ Listen to the motor: The motor should hum quietly and smoothly. ◦ Verify that the limits operate quietly and smoothly: investigate any unusual noise. • Verify that the mounting bolts are holding the unit securely. • Inspect the unit for evidence of corrosion. • Change the gear reducer's oil, at the very least, after every **2500 hours** of operation or once a year (if applicable).

1.2 Electrical Inspection

It is recommended that the electrical maintenance inspections, be performed at the same intervals as the mechanical maintenance inspections.

Table 10 - Electrical Inspection

Time Frame	Inspection
Every Month	• Inspect the unit for evidence of corrosion on electrical wires and connectors. • Inspect the wiring compartment and remove any dirt from the control units. • Verify all the grounding wires and terminals for corrosion. Be particularly careful to verify the ground wires. • Verify the terminal strip to insure that all the screws are tightened. • Verify that the pneumatic edge or other entrapment protection devices installed on the operator are fully operational. • Verify the voltage at the input terminals while the operator is running. The voltage must not drop more than 10% momentarily. If the voltage drop is too deep when running, the relays may chatter and the contact points will wear prematurely and may eventually seize. Verify the power terminals for corrosion. • Verify the current consumption of the unit with an amp-meter. The value of current should be consistent with the nameplate specifications. Investigate any anomaly.

2 Troubleshooting Guide

The electronic control board LEDs help with wiring and troubleshooting diagnostics. Every LED indicates the status of the door. The electronic control board has a non-volatile memory and the LEDs return to their initial state after a power interruption.

Easy Fix: Before starting any intervention, verify the LED's monitoring status and refer to Table 5, p.23 for a proper diagnosis.

Table 11 - Troubleshooting Guide - Part 1

Symptom	Probable Cause	Suggested Action
Door doesn't respond to any command	◆"Stop" button is stuck. (LED D9 is OFF)	➔ Press and release any "Stop" button.
	◆Control station is not connected or is wired incorrectly. (LED D9 is OFF)	➔ Verify and correct wiring.
	◆No power supply. (LED D2 is OFF)	➔ Verify the incoming power line from the main breaker, making sure it has not tripped or blown a fuse.
Operator is not operating as expected	◆Selector switch is not set on the desired mode.	➔ Set switch on desired mode, refer to p.25 for further details.
Timer to Close doesn't close the door	◆Timer to Close has been suspended accidentally for ONE cycle.	➔ Timer to Close will return to normal after the door has been fully closed. Refer to p.26 for further details.
Door doesn't respond to any radio command	◆No power supply. (Transmitter light is OFF)	➔ Replace the transmitter's battery.
	◆Transmitter is not properly programmed.	➔ Reprogram transmitter.
	◆Photo cells are not properly aligned or are obstructed.	➔ Clear the obstruction or re-align photo cells.
Door doesn't respond to "Open" command, but does respond to "Close" command	◆Defective "Open" push-button or "Open" limit switch.	➔ Replace push-button or limit switch.
	◆ Loose wire on "Open" push-button or "Open" limit switch.	➔ Verify and correct wiring.
Door doesn't respond to "Close" command, but does respond to "Open" command	◆Defective "Close" push-button or "Close" limit switch.	➔ Replace push-button or limit switch.
	◆Loose wire on "Close" push-button or "Close" limit switch.	➔ Verify and correct wiring.

Table 12 - Troubleshooting Guide - Part 2

Symptom	Probable Cause	Suggested Action
"Stop" button doesn't stop the door	◆Two 3-push button stations (or more) are connected in parallel.	➔ Verify and correct wiring (Stop buttons in series, only Open & Close in parallel).
Door reverses to fully open position after the door closes and reaches the floor	◆The "Close" limit switch is not being engaged by travelling cam.	➔ The "Close" limit switch needs to be adjusted properly at the end of travel.
	◆An "Open" command is being given.	➔ Verify "Open" push-button or any opening device for short-circuit.
Door doesn't open or close, motor hums or blows the main breaker	◆Mechanical door lock is engaged.	➔ Release the door lock.
	◆Door is jammed.	➔ Verify manual operation of door.
	◆Brake doesn't release, if applicable.	➔ Verify and adjust brake tension.
	◆Loose wire on solenoid brake, if applicable.	➔ Verify and correct wiring.
	◆Faulty solenoid brake, if applicable.	➔ Replace.
Motor hums when "Open" or "Close" buttons are pressed	◆Loose motor wires.	➔ Verify and correct wiring.
	◆Defective capacitor.	➔ Replace.
Motor fails to shut off at fully closed or fully opened positions	◆Defective limit switch.	➔ Operate limit switch manually while door is moving. If door does not stop, replace the switch.
	◆Limit cams are not adjusted.	➔ Verify and adjust.
	◆Limit drive chain is broken.	➔ Replace.
	◆Loose sprocket on limit shaft.	➔ Tighten set screw.
	◆Limit shaft does not rotate.	➔ Verify and replace accordingly.
Motor turns but door does not move	◆Sprocket key is missing.	➔ Replace.
	◆Drive chain is broken.	➔ Replace.
	◆Clutch is slipping.	➔ Adjust clutch to proper tension.
Limit switches do not hold their settings	◆Loose drive or limit chain.	➔ Adjust chain to proper tension.
	◆Limit cam retaining bracket is not engaging in the slots of the limit cams.	➔ Be sure it is engaged in slots of both cams.
	◆Limit cams are binding on shaft threads.	➔ Lubricate shaft threads. Limit cams should turn freely.
	◆Limit shaft has a slight "play".	➔ Verify and adjust.
Poor radio range	◆Transmitter battery is low.	➔ Verify and replace battery.
	◆Radio antenna is not properly positioned.	➔ Make sure antenna cable is not bent. Cable should be passed through control box.
	◆Ambient radio, environmental or building structure interference.	➔ Check connection of plug-in antenna. If required, add an external antenna (socket on receiver available).

3 Electrical Drawings

3.1 1 Phase Operator with BOARD 100E



Figure 30 - MECB11-B100-MLT-W

3.2 External Wiring with BOARD 100E



Figure 31 - External Wiring

4 Mechanical Exploded Views and Replacement Components

4.1 MLT



Figure 32 - MLT Mechanical Exploded View

Table 13 - MLT Replacement Components

No	Qty	Description	Manaras-Opera Part #	No	Qty	Description	Manaras-Opera Part #
1	2	5/8-24 HEX JAM NUT ZP	NUT015	7	1	MOTOR 1/2HP 115V/1PH 60HZ OPD 48Y	MOTOR189
2	1	CL.PAD 5/8x4x0.125"	CLUTCHPAD005	8	1	MOTOR PULLEY 1 1/2 X 1/2 4L	PULLEY011
3	1	CLUTCH SPRING 5/8	SPRING009	9	1	PULLEY 7" x 5/8" 5L/B	PULLEY020
4	1	CLUTCHPLATE 5/8	CLUTCHPLATE004	10	2	TYPE A PLAIN WASHER 5/8 N ZP	WASHER014
5	1	MDJ, MGT, MSJ, MTH, MTBH DRIVE	SHAFT048	11	1	V BELT A24	VBELTA24
6	1	MLT INPUT SHAFT 5/8-24X11-1/4	SHAFT086				

4.2 MLT Control Box with BOARD 100E



Figure 33 - MLT Control Box with BOARD 100E

Table 14 - Control Box Replacement Components (CBOX024)

No	Qty	Description	Manaras-Opera Part #
1	1	70 MF 250vac/B50/60HZ	CAPACITOR024
2	1	L. DUTY CONTROL BOX	CBOX024
3	2	LIMIT CAM	CAM005
4	1	MEDIUM DUTY ELECTRONIC CONTROL BOARD	BOARD100E
5	1	MLH LIMI DUTY SHAFT 5/8-18	SHAFT072
6	1	RADIO CONTROL TERM STRIP	TSTRIP005
7	2	SINGLE LIMIT SWITCH - LEVER 46 DEG	LIMIT023

Notes

Warranty

Manaras-Opera warrants its operators to be free from defects in material and workmanship under normal and proper use for a period of two years from date of invoice. Mechanical, electrical and electronic accessories are warranted for one year from date of invoice. Wearing parts such as clutch pads, v-belts, and brake bands are excluded from warranty.

Manaras-Opera's only obligation shall be to repair or replace defective equipment which does not conform to the warranty. Manaras-Opera shall not be liable for any injury, loss or damage, direct or consequential, arising out of the inability to use the equipment. Before using, Buyer and/or the ultimate User shall determine the suitability of the product for its intended use, and User assumes all risks and liability in connection therewith. The foregoing may not be changed except by an Agreement signed by an authorized representative of Manaras-Opera.

The articles that are replaced pursuant to the terms of this warranty shall be retained by Manaras-Opera, and the User is responsible for any freight costs relating to repair or replacement.

The foregoing warranty is exclusive and in lieu of all other warranties of quality, whether written, oral or implied (including any other warranty of merchantability or fitness for purpose).

The following are exclusions from warranty:

- If usage, product modification, adaptation or installation are not in accordance with our installation and operating instructions.
- If the product has been opened, dismantled or returned with clear evidence of abuse or other damage.
- If our written specifications are not properly applied by the Buyer when selecting the equipment.
- If our written instructions for installation and wiring of the electrical connections have not been followed.
- If our equipment has been used to perform functions other than the functions it was designed to handle.
- If Manaras-Opera equipment is used with electrical accessories (switches, relays, etc.) that have not been previously approved in writing by the Manaras-Opera Engineering Department.
- If electrical accessories and other components have been used in disregard of the basic wiring diagram for which they were designed.

All costs related to installation and re-installation of the Manaras-Opera equipment covered by this warranty are not the responsibility of Manaras-Opera. Manaras-Opera will not be responsible for any consequential damages following installation procedures performed by the Buyer or End-user. If the Buyer resells any Manaras-Opera products to another Buyer or End-user, it shall include all of the terms and provisions of this warranty in such resale. Manaras-Opera's responsibility to any such Third Party shall be no greater than Manaras-Opera's responsibility under the warranty to the original Buyer.

Returns

No returns will be accepted without prior written authorization by Manaras-Opera. All returns must be accompanied by a Return Authorization Number issued by Manaras-Opera, and all unauthorized returns will be refused. The return shipment is to be freight prepaid by the Buyer, and under no circumstances shall the Buyer deduct the value of the returned merchandise from any remittance due. A restocking fee of 15% of Manaras-Opera sale price will be charged.

Commercial Door OPERAtor

Manaras-Opera is extending their well-known OPERA brand name across its entire line of Commercial Door OPERAtors. Over the years, the OPERA brand name has become synonymous with innovation and reliability. The high quality products you have come to expect from us will now be backed by the OPERA brand name.

When you think Commercial Door OPERAtors, just think OPERA.

Call us for more information
1-800-361-2260

www.manaras.com

Reg. T.M. of 9141-0720 Québec Inc.